


MUTIMEDIA PROJECTOR MODEL XR-55X XR-50S

OPERATION MANUAL







IMPORTANT

- For your assistance in reporting the loss or theft of your Projector, please record the Model and Serial Number located on the bottom of the projector and retain this information.
- Before recycling the packaging, please ensure that you have checked the contents of the carton thoroughly against the list of "Supplied accessories" on page 11.

Model No.:

Serial No.:

SPECIAL NOTE FOR USERS IN THE U.K.

The mains lead of this product is fitted with a non-rewireable (moulded) plug incorporating a 10A fuse. Should the fuse need to be replaced, a BSI or ASTA approved BS 1362 fuse marked \heartsuit or O and of the same rating as above, which is also indicated on the pin face of the plug, must be used.

Always refit the fuse cover after replacing the fuse. Never use the plug without the fuse cover fitted.

In the unlikely event of the socket outlet in your home not being compatible with the plug supplied, cut off the mains plug and fit an appropriate type.

DANGER:

The fuse from the cut-off plug should be removed and the cut-off plug destroyed immediately and disposed of in a safe manner.

Under no circumstances should the cut-off plug be inserted elsewhere into a 13A socket outlet, as a serious electric shock may occur.

To fit an appropriate plug to the mains lead, follow the instructions below:

WARNING:

THIS APPARATUS MUST BE EARTHED.

IMPORTANT:

The wires in this mains lead are coloured in accordance with the following code:

Green-and-yellow	: Earth
Blue	: Neutral
Brown	: Live

As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured markings identifying the terminals in your plug proceed as follows:

- The wire which is coloured green-and-yellow must be connected to the terminal in the plug which is marked by the letter E or by the safety earth symbol $\frac{1}{2}$ or coloured green or green-and-yellow.
- The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black.
- The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

IF YOU HAVE ANY DOUBT, CONSULT A QUALIFIED ELECTRICIAN.

Authorized representative responsible for the European Union Community Market

SHARP ELECTRONICS (Europe) GmbH Sonninstraße 3, D-20097 Hamburg

E.U. ONLY

The supplied CD-ROM contains operation instructions in English, German, French, Spanish, Italian, Dutch, Swedish, Portuguese, Chinese, Korean and Arabic. Carefully read through the operation instructions before operating the projector.

Die mitgelieferte CD-ROM enthält Bedienungsanleitungen in Englisch, Deutsch, Französisch, Spanisch, Italienisch, Niederländisch, Schwedisch, Portugiesisch, Chinesisch, Koreanisch und Arabisch. Bitte lesen Sie die Bedienungsanleitung vor der Verwendung des Projektors sorgfältig durch.

Le CD-ROM fourni contient les instructions de fonctionnement en anglais, allemand, français, espagnol, italien, néerlandais, suédois, portugais, chinois, coréen et arabe. Veuillez lire attentivement ces instructions avant de faire fonctionner le projecteur.

El CD-ROM suministrado contiene instrucciones de operación en inglés, alemán, francés, español, italiano, holandés, sueco, portugués, chino, coreano y árabe. Lea cuidadosamente las instrucciones de operación antes de utilizar el proyector.

Il CD-ROM in dotazione contiene istruzioni per l'uso in inglese, tedesco, francese, spagnolo, italiano, olandese, svedese, portoghese, cinese, coreano e arabo. Leggere attentamente le istruzioni per l'uso prima di usare il proiettore.

De meegeleverde CD-ROM bevat handleidingen in het Engels, Duits, Frans, Spaans, Italiaans, Nederlands, Zweeds, Portugees, Chinees, Koreaans en Arabisch. Lees de handleiding zorgvuldig door voor u de projector in gebruik neemt.

Den medföljande CD-ROM-skivan innehåller bruksanvisningar på engelska, tyska, franska, spanska, italienska, holländska, svenska, portugisiska, kinesiska, koreanska och arabiska. Läs noga igenom bruksanvisningen innan projektorn tas i bruk.

O CD-ROM fornecido contém instruções de operação em Inglês, Alemão, Francês, Espanhol, Italiano, Holandês, Sueco, Português, Chinês, Coreano e Árabe. Leia cuidadosamente todas as instruções de operação antes de operar o projetor.

附送之CD-ROM光碟中,有用英文、德文、法文、西班牙文、意大利文、荷蘭文、瑞典文、葡萄牙文、 中文、韓國文和阿拉伯文所寫的使用說明書。在操作本投影機之前,請務必仔細閱讀整本使用說明書。

제공된 CD-ROM에는 영어, 독일어, 프랑스어, 스페인어, 이탈리아어, 네덜란드어, 스웨덴어, 포르투갈어, 중국어, 한국어, 아라비아어로 작성된 조작 설명서가 수록되어 있습니다. 프로젝터를 조작하기 전에 조작 지침을 상세하게 숙지하십시오.

يحتوي القرص المضغوط المرفق مع المنتج على تعليمات التشغيل باللغة الإنجليزية، الألمانية، الفرنسية، الإسبانية، الإيطالية، الهولندية، السويدية، البرتغالية، الصينية، الكورية والعربية. برجاء قراءة تعليمات التشغيل بعناية قبل الشروع في تشغيل جهاز الإسقاط. Introduction

There are two important reasons for prompt warranty registration of your new SHARP Projector, using the REGISTRATION CARD packed with the projector.

1. WARRANTY

This is to assure that you immediately receive the full benefit of the parts, service and labor warranty applicable to your purchase.

2. CONSUMER PRODUCT SAFETY ACT

To ensure that you will promptly receive any safety notification of inspection, modification, or recall that SHARP may be required to give under the 1972 Consumer Product Safety Act, PLEASE READ CAREFULLY THE IMPORTANT "LIMITED WARRANTY" CLAUSE.

WARNING: High brightness light source. Do not stare into the beam of light, or view directly. Be especially careful that children do not stare directly into the beam of light.

WARNING: To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.

See bottom of projector.

CAUTION

RISK OF ELECTRIC SHOCK.

DO NOT REMOVE SCREWS

EXCEPT SPECIFIED USER

SERVICE SCREW.


CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK

DO NOT REMOVE COVER.

NO USER-SERVICEABLE PARTS EXCEPT LAMP UNIT.

REFER SERVICING TO QUALIFIED SERVICE

PERSONNEL.



The exclamation point within a triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

WARNING: FCC Regulations state that any unauthorized changes or modifications to this equipment not expressly approved by the manufacturer could void the user's authority to operate this equipment.

PRODUCT DISPOSAL

This product utilizes tin-lead solder, and lamp containing a small amount of mercury. Disposal of these materials may be regulated due to environmental considerations. For disposal or recycling information, please contact your local authorities, the Electronics Industries Alliance: www.eiae.org, the lamp recycling organization www.lamprecycle.org, or Sharp at 1-800-BE-SHARP.

ENGLISH

Introduction

INFORMATION

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the operation manual, may cause harmful interference to radio communications. However, there is no guarantee that interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

U.S.A. ONLY

Declaration of conformity

SHARP PROJECTOR, MODEL XR-55X/XR-50S

This device complies with Part 15 of the FCC rules. Operation is subject to the following conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Responsible Party:

SHARP ELECTRONICS CORPORATION

Sharp Plaza, Mahwah, New Jersey 07495-1163

TEL: 1-800-BE-SHARP (1-800-237-4277)

U.S.A. ONLY

Caution Concerning Lamp Replacement

This projector utilizes a pressurized mercury lamp. A loud sound may indicate lamp failure. Lamp failure can be attributed to numerous sources such as: excessive shock, improper cooling, surface scratches or deterioration of the lamp due to a lapse of usage time. The period of time up to failure largely varies depending on the individual lamp and/or the condition

I he period of time up to failure largely varies depending on the individual lamp and/or the condition and the frequency of use. It is important to note that failure can often result in the bulb cracking. When the lamp replacement indicator and on-screen display icon are illuminated, it is recommended

- When the lamp replacement indicator and on-screen display icon are intrinated, it is recommended, that the lamp be replaced with a new one immediately, even if the lamp appears to be operating normally.
- Should the lamp break, there is also a possibility that glass particles may spread inside of the projector. In such a case, it is recommended you contact your nearest Sharp Authorized Projector Dealer or Service Center to assure safe operation.
- Should the lamp break, the glass particles may spread inside the lamp cage or gas contained in the lamp may be vented into the room from the exhaust vent. Because the gas in this lamp includes mercury, ventilate the room well if the lamp breaks and avoid all exposure to the released gas. In case of exposure to the gas, consult a doctor as soon as possible.

Caution


- Do not remove the lamp unit from the projector right after use. The lamp will be very hot and may cause burns or injury.
- Wait at least one hour after the power cord is disconnected to allow the surface of the lamp unit to fully cool before removing the lamp unit.
- Do not touch the glass surface of the lamp unit or the inside of the projector.
- Do not loosen other screws except for the lamp unit cover and lamp unit.
- Make sure to reset the lamp timer only when replacing the lamp. If you reset the lamp timer and continue to use the same lamp, this may cause the lamp to become damaged or explode.
- Carefully change the lamp by following the instructions described on pages 56 to 58. * If you wish, you may have the lamp replaced at your nearest Sharp Authorized Projector Dealer or Service Center.

If the new lamp does not light after replacement, take your projector to the nearest Sharp Authorized Projector Dealer or Service Center for repair.

Introduction


How to Read this Operation Manual

- The specifications are slightly different, depending on the model. However, you can connect and operate all models in the same manner.
- In this operation manual, the illustration and the screen display are simplified for explanation, and may differ slightly from the actual display. The examples used throughout this manual are based on the XR-55X model.



Note Indicates additional information for setting up and operating the projector.

For Future Reference



Contents

Preparing

Introduction

How to Read this Operation Manual	3
Contents	4
IMPORTANT SAFEGUARDS	6
How to Access the PDF Operation	
Manuals	10
Accessories	11
Part Names and Functions	12
Front View	
Top View	
Rear View (Terminals)	
Inserting the Batteries	
Usable Range	15

Easy Start

Easy Start	16
Setup and Projection 1	6

Setup

Setting Up the Projector	18
Setting Up the Projector	
Standard Setup (Front Projection)	
Screen Size and Projection Distance .	19
Projection (PRJ) Mode	20
Ceiling-Mount Setup	20

Connections

Connecting the Projector to	
Other Equipment	.21
Controlling the Projector by	
a Computer	.24
Connecting the Power Cord	.24

Using

Basic Operation

Turning the Projector On)
Duris standate Otan allow Manda)	
Projector into Standby Mode) 25	
Image Projection26	;
About the Setup Guide	
Adjusting the Projected Image	
Correcting Trapezoidal Distortion	
Switching the Input Mode	
Adjusting the Volume	

Displaying the Black Screen and
Turning Off the Sound Temporarily 29
Resize Mode

Useful Features

Operating with the Remote Control	32
Displaying and Setting the	
Break Timer	. 32
Displaying the Pointer	
Using the Spot Function	
Switching the Eco+Quiet Mode	
Auto Sync (Auto Sync Adjustment)	. 33
Freezing a Moving Image	. 33
Selecting the Picture Mode	. 33
Displaying an Enlarged Portion of	
an Image	. 33
Using the Remote Control as the	
Wireless Computer Mouse	
Menu Items	35
Using the Menu Screen	38
Menu Selections (Quick Start Menu)	38
Quick Start Menu	. 39
Menu Selections (Complete Menu)	. 39
Picture Adjustment ("Picture" Menu)	41
Selecting the Picture Mode	
Adjusting the Image	
Adjusting the Color Temperature	. 42
Adjusting the Colors	42
Selecting the Film Mode	
Reducing Image Noise (DNR)	43
Eco+Quiet	. 43
Signal Adjustment ("SIG-ADJ" Menu)44
Adjusting the Computer Image	44
Resolution Setting	44
Signal Type Setting	
Setting the Video System	45
Setting the Video Setup	45
Checking the Input Signal	45
Adjusting the Projected Image	
("SCR - ADJ" Menu)	46
Setting the Resize Mode	4 0
Adjusting the Image Position	. 40
Keystone Correction	40
Setting the Overscan	. 40
Setting the On-screen Display	. 47
Closed Caption	
Selecting the Background Image	
Selecting the Setup Guide	
Reversing/Inverting Projected Images	. 40 10
Selecting the Wall Color	
Selecting the On-screen Display Language	
Selecting the On-screen Display Language	. 40

Adjusting the Projector Function

("PRJ-ADJ1/2" Menu)	49
Auto Sync (Auto Sync Adjustment)	49
Auto Power Off Function	49
Auto Restart Function	49
Speaker Setting	49
Selecting the Transmission Speed	
(RS-232C)	49
Fan Mode Setting	50
System Lock Function	50
Keylock Function	51
Selecting the Quick Start Menu	51
Setting the FUNCTION Button Operation	51
STANDBY Mode	52
DLP [®] Link [™]	52
DLP [®] Link [™] Invert	52
Returning to the Default Settings	52
Checking the Lamp Life Status	52

Reference

Appendix

Maintenance	53
Maintenance Indicators	54
Regarding the Lamp	56
Lamp	
Caution Concerning the Lamp	56
Replacing the Lamp	56
Removing and Installing the	
Lamp Unit	
Resetting the Lamp Timer	
Connecting Pin Assignments	59
RS-232C Specifications and	
Commands	
Computer Compatibility Chart	66
Troubleshooting	67
For SHARP Assistance	68
Specifications	70
Dimensions	71
Index	

IMPORTANT SAFEGUARDS

CAUTION: Please read all of these instructions before you operate this product and save these instructions for later use.

Electrical energy can perform many useful functions. This product has been engineered and manufactured to assure your personal safety. BUT IMPROPER USE CAN RESULT IN POTENTIAL ELECTRICAL SHOCK OR FIRE HAZARDS. In order not to defeat the safeguards incorporated in this product, observe the following basic rules for its installation, use and servicing.

1. Read Instructions

All the safety and operating instructions should be read before the product is operated.

2. Retain Instructions

The safety and operating instructions should be retained for future reference.

3. Heed Warnings

All warnings on the product and in the operating instructions should be adhered to.

4. Follow Instructions

All operating and use instructions should be followed.

5. Cleaning

Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

6. Attachments

Do not use attachments not recommended by the product manufacturer as they may cause hazards.

7. Water and Moisture

Do not use this product near water-for example, near a bath tub, wash bowl, kitchen sink, or laundry tub; in a wet basement; or near a swimming pool; and the like.

8. Accessories

Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

9. Transportation

A product and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the product and cart combination to overturn.



10. Ventilation

Slots and openings in the cabinet are provided for ventilation to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.

11. Power Sources

This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions.

12. Grounding or Polarization

This product is provided with one of the following types of plugs. If the plug should fail to fit into the power outlet, please contact your electrician.

Do not defeat the safety purpose of the plug.

- a. Two-wire type (mains) plug.
- b. Three-wire grounding type (mains) plug with a grounding terminal. This plug will only fit into a grounding type power outlet.

13. Power-Cord Protection

Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.

14. Lightning

For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the cable system. This will prevent damage to the product due to lightning and power-line surges.

15. Overloading

Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.

16. Object and Liquid Entry

Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.

17. Servicing

Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

18. Damage Requiring Service Unplug this product from the wall outlet

and refer servicing to qualified service personnel under the following conditions:

- a. When the power-supply cord or plug is damaged.
- b. If liquid has been spilled, or objects have fallen into the product.
- c. If the product has been exposed to rain or water.
- d. If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions, as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal operation.
- e. If the product has been dropped or damaged in any way.
- f. When the product exhibits a distinct change in performance, this indicates a need for service.

19. Replacement Parts

When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.

20. Safety Check

Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.

21. Wall or Ceiling Mounting

This product should be mounted to a wall or ceiling only as recommended by the manufacturer.

22. Heat

This product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

- DLP[®] and the DLP logo are registered trademarks of Texas Instruments and BrilliantColor[™] and DLP[®] Link[™] are trademarks of Texas Instruments.
- Microsoft® and Windows® are registered trademarks of Microsoft Corporation in the United States and/or other countries.
- PC/AT is a registered trademark of International Business Machines Corporation in the United States.
- Adobe® Reader® is a trademark of Adobe Systems Incorporated.
- Macintosh® is a registered trademark of Apple Computer, Inc. in the United States and/or other countries.
- All other company or product names are trademarks or registered trademarks of their respective companies.
- Some IC chips in this product include confidential and/or trade secret property belonging to Texas Instruments. Therefore you may not copy, modify, adapt, translate, distribute, reverse engineer, reverse assemble or discompile the contents thereof.

Observe the following safeguards when setting up your projector.

Caution concerning the lamp unit

Potential hazard of glass particles if lamp ruptures. In case of lamp rupture, contact your nearest Sharp Authorized Projector Dealer or Service Center

for replacement. See "Regarding the Lamp' on page 56.



Caution concerning the setup of the projector

■ For minimal servicing and to maintain high image quality, SHARP recommends that this projector be installed in an area free from humidity, dust and cigarette smoke. When the projector is subjected to these environments, the vents and lens must be cleaned more often. As long as the projector is regularly cleaned, use in these environments will not reduce the overall operation life of the unit. Internal cleaning should only be performed by a Sharp Authorized Projector Dealer or Service Center.

Rest your eyes occasionally.


Continuously watching the screen for long hours will cause eye strain. Take regular breaks to rest your eyes.

Do not set up the projector in places exposed to direct sunlight or bright light.

Position the screen so that it is not in direct sunlight or room light. Light falling directly on the screen washes out the colors, making viewing difficult. Close the curtains and dim the lights when setting up the screen in a sunny or bright room.

Caution regarding placing of the projector

Place the projector on a level site within the adjustment range (9 degrees) of the adjustment foot.



After the projector is purchased, a faint smell from the vent may appear when the power is first turned on. This is normal and is not a malfunction. It will disappear after the projector is used for a while. When using the projector in highaltitude areas such as mountains (at altitudes of approximately 1,500 meters (4,900 feet) or more)

- When you use the projector in high-altitude areas with thin air, set "Fan Mode" to "High". Neglecting this can affect the longevity of the optical system.
- Use the projector at altitudes of 2,300 meters (7,500 feet) or less.

Warning about placing the projector in a high position

When placing the projector in a high position, make certain it is carefully secure to avoid personal injury caused by the projector falling down.

Do not subject the projector to hard impact and/or vibration.

Protect the lens so as not to hit or damage the surface of the lens.

Avoid locations with extremes of temperature.

- The operating temperature of the projector is from 41°F to 95°F (+5°C to +35°C).
- The storage temperature of the projector is from -4°F to 140°F (-20°C to +60°C).

Do not block the exhaust and intake vents.

- Allow at least 11 ¹³/₁₆ inches (30 cm) of space between the exhaust vent and the nearest wall or obstruction.
- Ensure that the intake vent and the exhaust vent are not obstructed.
- If the cooling fan becomes obstructed, a protection circuit will automatically put the projector into Standby mode to prevent overheat damage. This does not indicate a malfunction. (See pages 54 and 55.) Remove the projector power cord from the wall outlet and wait at least 10 minutes. Place the projector where the intake and exhaust vents are not blocked, plug the power cord back in and turn on the projector. This will return the projector to the normal operating condition.

Caution regarding usage of the projector

- If you are not to use the projector for a long time or before moving the projector, make certain you unplug the power cord from the wall outlet, and disconnect any other cables connected to it.
- Do not carry the projector by holding the lens.
- When storing the projector, ensure that you close the lens shutter.
- Do not expose the projector to direct sunlight or place next to heat sources. Doing so may affect the cabinet color or cause deformation of the plastic cover.

Other connected equipment

- When connecting a computer or other audio-visual equipment to the projector, make the connections AFTER unplugging the power cord of the projector from the AC outlet and turning off the equipment to be connected.
- Please read the operation manuals of the projector and the equipment to be connected for instructions on how to make the connections.

Using the projector in other countries

The power supply voltage and the shape of the plug may vary depending on the region or country you are using the projector in. When using the projector overseas, make sure you use an appropriate power cord for the country you are in.

Temperature monitor function



■ If the temperature inside the projector increases, due to blockage of the air vents, or the setting location, the temperature warning indicator will blink. And if the temperature keeps on rising, "<u>Y terr</u>" will illuminate in the lower left corner of the picture with the temperature warning indicator blinking. If this state continues, the lamp will turn off, the cooling fan will run and then the projector will enter Standby mode. Refer to "Maintenance Indicators" on pages 54 and 55 for details.

📕 Info

• The cooling fan regulates the internal temperature, and its performance is automatically controlled. The sound of the fan may change during projector operation due to changes in the fan speed. This does not indicate malfunction.

Closed Caption uses Bitstream Vera fonts

to the following conditions:

Copyright (c) 2003 by Bitstream, Inc. All Rights Reserved. Bitstream Vera is a trademark of Bitstream, Inc. Permission is hereby granted, free of charge, to any person obtaining a copy of the fonts accompanying this license ("Fonts") and associated documentation files (the "Font Software"), to reproduce and distribute the Font Software, including without limitation the rights to use, copy, merge, publish, distribute, and/or sell copies of the Font Software, and to permit persons to whom the Font Software is furnished to do so, subject

The above copyright and trademark notices and this permission notice shall be included in all copies of one or more of the Font Software typefaces.

The Font Software may be modified, altered, or added to, and in particular the designs of glyphs or characters in the Fonts may be modified and additional glyphs or characters may be added to the Fonts, only if the fonts are renamed to names not containing either the words "Bitstream" or the word "Vera".

This License becomes null and void to the extent applicable to Fonts or Font Software that has been modified and is distributed under the "Bitstream Vera" names.

The Font Software may be sold as part of a larger software package but no copy of one or more of the Font Software typefaces may be sold by itself.

THE FONT SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OF COPYRIGHT, PATENT, TRADEMARK, OR OTHER RIGHT. IN NO EVENT SHALL BITSTREAM OR THE GNOME FOUNDATION BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, INCLUDING ANY GENERAL, SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF THE USE OR INABILITY TO USE THE FONT SOFTWARE OR FROM OTHER DEALINGS IN THE FONT SOFTWARE.

Except as contained in this notice, the names of Gnome, the Gnome Foundation, and Bitstream Inc., shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Font Software without prior written authorization from the Gnome Foundation or Bitstream Inc., respectively. For further information, contact: fonts at gnome dot org.

How to Access the PDF Operation Manuals

PDF operation manuals in several languages are included in the CD-ROM. To utilize these manuals, you need to install Adobe[®] Reader[®] on your computer (Windows[®] or Macintosh[®]).

Please download Adobe® Reader® from the Internet (http://www.adobe.com).

Accessing the PDF Manuals for Windows® (For Macintosh®, skip step 2).


- ① Insert the CD-ROM in the CD-ROM drive.
- (2) Double click the "My Computer" icon.
- ③ Double click the "CD-ROM" drive.
- (4) Double click the "MANUALS" folder.
- (5) Double click the model (name of the folder) that you want to view.
- (6) Double click the language (name of the folder) that you want to view.
- \bigcirc Double click the pdf file to access the projector manuals.

Note

• If the desired pdf file cannot be opened by double clicking the mouse, start Adobe® Reader® first, then specify the desired file using the "File", "Open" menu.

Accessories


Supplied accessories



Note

• Codes in "< >" are Replacement parts codes.

Optional accessories




AN-60KT AN-XRCM30 (for U.S.A. only) AN-TK201 <for AN-60KT> AN-TK202 <for AN-60KT> AN-EP101B <for AN-XRCM30> (for U.S.A. only) AN-MR2 AN-C3CP2 AN-A1RS


Note

• Some of the optional accessories may not be available depending on the region. Please check with your nearest Sharp Authorized Projector Dealer or Service Center.

Part Names and Functions

Numbers in **T** refer to the main pages in this operation manual where the topic is explained.






Front View

- 1 Exhaust vent 53
- 2 Zoom ring 27 For enlarging/reducing the picture.
- **3** Focus ring **26** For adjusting the focus.
- 4 Lens shutter 25, 29
- 5 HEIGHT ADJUST lever 27
- 6 Adjustment foot 27
- 7 Remote control sensor 15
- 8 Speaker 49
- 9 Intake vent 53

Top View

- 10 Temperature warning indicator 54
- 11 Lamp indicator 54
- 12 Power indicator 54
- **13** STANDBY/ON button **25** For turning the power on and putting the projector into Standby mode.
- 14 INPUT buttons (▲/▼) 29 For switching Input mode.
- **15** AUTO SYNC button **33** For automatically adjusting images when connected to a computer.
- 16 Adjustment buttons (▲/▼/◀/►) 38 For selecting menu items.
- 17 ENTER button 38 For setting items selected or adjusted on the menu.
- **18** MENU button **38** For displaying adjustment and setting screens.
- **19** VOL (Volume) buttons (-◄/►+) **29** For adjusting the speaker sound level.



Rear View (Terminals)

- **1** RS-232C terminal **24** Terminal for controlling the projector using a computer.
- **2** USB terminal **34** Terminal connecting with the USB terminal on the computer for using the supplied remote control as the computer mouse.
- 3 MONITOR OUT terminal 23 (Output terminal for computer RGB and component signals.) Terminal for connecting a monitor.
- 4 AUDIO 1 input terminal 23
- 5 COMPUTER/COMPONENT input terminal 21, 22 Terminal for computer RGB and component

signals.

- 6 S-VIDEO input terminal 22 Terminal for connecting video equipment with an S-video terminal.
- 7 VIDEO input terminal 22 Terminal for connecting video equipment.
- 8 AUDIO 2 input terminal 23
- 9 AC socket 24 Connect the supplied power cord.
- 10 Kensington Security Standard connector
- 11 Rear adjustment foot 27
- 12 Security bar

Using the Kensington Lock

• This projector has a Kensington Security Standard connector for use with a Kensington MicroSaver Security System. Refer to the information that came with the system for instructions on how to use it to secure the projector.

Part Names and Functions (Continued)

Numbers in **T** refer to the main pages in this operation manual where the topic is explained.

- (\mathbf{l}) 2 14 3 4 Ő 15 Q 16 5 6 17 7 SPO 8 18 19 9 HCIICK 20 10 21 11 DE 22 12 13 23
- 1 ON button 25 For turning the power on.
- 2 STANDBY button 25 For putting the projector into the Standby mode.
- 3 INPUT buttons (∧ / √) 29 For switching Input mode.
- 4 BREAK TIMER button 32 For displaying the break time.
- 5 MAGNIFY buttons 33 For enlarging/reducing part of the image.
- 6 PAGE UP/PAGE DOWN buttons 34 Same as the [Page Up] and [Page Down] keys on a computer keyboard, when with the USB connection (using a USB cable or the optional remote receiver).
- 7 POINTER button 32 For displaying the pointer.
- 8 MOUSE/Adjustment buttons (▲/▼/◄/►) 34, 38
 For moving the computer cursor when with the USB connection (using a USB cable or the optional remote receiver).
 - For selecting and adjusting menu items.

- 9 L-CLICK/EFFECT button 34, 32
 - For the Left click when with the USB connection (using a USB cable or the optional remote receiver).
 - For changing the pointer or spot area.
- **10** KEYSTONE button **28** For entering the Keystone Correction mode.
- **11** AUTO SYNC button **33, 49** For automatically adjusting images when connected to a computer.
- **12** FUNCTION button **51** For operating and executing a function assigned to "FUNCTION Button".
- **13** ECO+QUIET button **32** For lowering the noise of the cooling fan and extending the lamp life.
- **14** FREEZE button **33** For freezing images.
- **15** AV MUTE button **29** For temporarily displaying a black screen and turning off the sound.
- 16 VOL +/- (Volume) buttons 29 For adjusting the speaker sound level.
- **17** SPOT button **32** For displaying the spotlight.
- **18** ENTER button **38**

For setting items selected or adjusted on the menu.


- 19 R-CLICK/RETURN button 34, 38
 - For the Right click when with the USB connection (using a USB cable or the optional remote receiver).
 - For returning to the previous menu screen during menu operations.
- 20 MENU button 38

For displaying adjustment and setting screens.

- 21 RESIZE button 30 For switching the picture size (NORMAL, 16:9. etc.).
- 22 3D MODE button (XR-55X only) See the Operation Manual for Stereoscopic 3D Projection provided separately.
- **23** PICTURE MODE button **33** For selecting the appropriate picture.


Introduction

Inserting the Batteries



- **2** Insert the batteries.
 - Insert the batteries making sure the polarities correctly match the ⊕ and ⊖ marks inside the battery compartment.

3 Insert the lower tab of the cover into the opening, and lower the cover until it clicks in place.



Incorrect use of the batteries may cause them to leak or explode. Please follow the precautions below

Caution

- Danger of explosion if battery is incorrectly replaced. Replace only with alkaline or manganese batteries.
- Insert the batteries making sure the polarities correctly match the \oplus and \bigcirc marks inside the battery compartment.
- Batteries of different types have different properties, therefore do not mix batteries of different types.
- Do not mix new and old batteries.
- This may shorten the life of new batteries or may cause old batteries to leak.
- Remove the batteries from the remote control once they have run out, as leaving them in can cause them to leak. Battery fluid from leaked batteries is harmful to skin, therefore ensure you wipe them first and then remove them using a cloth.
- The batteries included with this projector may run down in a short period, depending on how they are kept. Be sure to replace them as soon as possible with new batteries.
- Remove the batteries from the remote control if you will not be using the remote control for a long time.
- Comply with the rules (ordinance) of each local government when disposing of worn-out batteries.

Usable Range


The remote control can be used to control the projector within the ranges shown in the illustration.

🗞 Note

 The signal from the remote control can be reflected off a screen for easy operation.
 However, the effective distance of the signal may differ depending on the screen material.

When using the remote control

- Ensure that you do not drop it or expose it to moisture or high temperature.
- The remote control may malfunction under a fluorescent lamp. In this case, move the projector away from the fluorescent lamp.



Remote control


Remote control sensor

Easy Start

This section shows the basic operation (projector connecting with the computer). For details, see the page described below for each step.


Setup and Projection

In this section, connection of the projector and the computer is explained using one example.



4. Adjust the projected image with the Setup Guide

- 1 After the projector turns on, the Setup Guide appears. (When "Setup Guide" is set to "On". See page 48.)
- 2 Follow the steps in the Setup Guide and adjust the focus, height (angle) and picture size.
- **3** After adjusting the focus, height (angle) and picture size, press **ENTER** to finish the Setup Guide.



Press **STANDBY/ON** on the projector or **STANDBY** on the remote control, and then press the button again while the confirmation message is displayed to put the projector into Standby mode.

On the projector

On the remote control

STANDBY





On-screen display

Enter STANDBY mode?
 Yes : Press Again
 No : Please Wait

➡ P. 25

Easy Start

Setting Up the Projector

Setting Up the Projector

For optimal image quality, position the projector perpendicular to the screen with the projector's feet flat and level. Doing so will eliminate the need for Keystone correction and provide the best image quality. (See page **28**.)


Standard Setup (Front Projection)


Place the projector at the required distance from the screen according to the desired picture size. (See page 19.)



Indication of the Projection Image Size and Projection Distance

Example: 4:3 Signal Input (Normal Mode)





Screen Size and Projection Distance

4:3 Signal Input (Normal Mode)

Pie	Picture (Screen) size Projection distance [L]			Distance from the lens center	
Diagonal [%]	Width	Height	Minimum [L1]	Maximum [L2]	to the bottom of the image [H]
300" (762 cm)	610 cm (240")	457 cm (180")	10.4 m (34' 0")	12.6 m (41'3")	18 cm (7 1/4")
250" (635 cm)	508 cm (200")	381 cm (150")	8.6 m (28' 4")	10.5 m (34' 4")	15 cm (6 1/32")
200" (508 cm)	406 cm (160")	305 cm (120")	6.9 m (22' 8")	8.4 m (27' 6")	12 cm (4 53/64")
150" (381 cm)	305 cm (120")	229 cm (90")	5.2 m (17' 0")	6.3 m (20' 7")	9 cm (3 5/8")
120" (305 cm)	244 cm (96")	183 cm (72")	4.1 m (13' 7")	5.0 m (16' 6")	7 cm (2 57/64")
100" (254 cm)	203 cm (80")	152 cm (60")	3.5 m (11' 4")	4.2 m (13' 9")	6 cm (2 27/64")
80" (203 cm)	163 cm (64")	122 cm (48")	2.8 m (9' 1")	3.3 m (11' 0")	5 cm (1 15/16")
70" (178 cm)	142 cm (56")	107 cm (42")	2.4 m (7' 11")	2.9 m (9' 7")	4 cm (1 11/16")
60" (152 cm)	122 cm (48")	91 cm (36")	2.1 m (6' 10")	2.5 m (8' 3")	4 cm (1 29/64")
40" (102 cm)	81 cm (32")	61 cm (24")	1.4 m (4' 6")	1.7 m (5' 6")	2 cm (³¹ / ₃₂ ")

16:9 Signal Input (16:9 Mode)

Picture (Screen) size		Projection distance [L]		Distance from the lens center	Adjustable range of	
Diagonal [χ]	Width	Height	Minimum [L1]	Maximum [L2]	to the bottom of the image [H]	image position [S]
300" (762 cm)	664 cm (261")	374 cm (147")	11.3 m (37' 1")	13.7 m (44' 11'')	82 cm (32 13/32")	±62 cm (±24 ³³ / ₆₄ ")
250" (635 cm)	553 cm (218")	311 cm (123'')	9.4 m (30' 11")	11.4 m (37' 5")	69 cm (27")	±52 cm (±20 ²⁷ / ₆₄ ")
200" (508 cm)	443 cm (174")	249 cm (98'')	7.5 m (24' 9")	9.1 m (29' 11'')	55 cm (21 39/64")	±42 cm (±16 11/32")
150" (381 cm)	332 cm (131")	187 cm (74")	5.6 m (18' 6")	6.8 m (22' 5")	41 cm (16 13/64")	±31 cm (±12 1/4")
120" (305 cm)	266 cm (105")	149 cm (59")	4.5 m (14' 10")	5.5 m (18' 0")	33 cm (12 31/32")	±25 cm (±9 ¹³ / ₁₆ ")
100" (254 cm)	221 cm (87")	125 cm (49'')	3.8 m (12' 4")	4.6 m (15' 0")	27 cm (10 51/64")	±21 cm (±8 11/64")
80" (203 cm)	177 cm (70")	100 cm (39'')	3.0 m (9' 11")	3.6 m (12' 0")	22 cm (8 41/64")	±17 cm (±6 17/32")
60" (152 cm)	133 cm (52'')	75 cm (29'')	2.3 m (7′ 5″)	2.7 m (9' 0")	16 cm (6 31/64")	±12 cm (±4 29/32")
40" (102 cm)	89 cm (35'')	50 cm (20'')	1.5 m (4' 11")	1.8 m (6' 0'')	11 cm (4 ²¹ / ₆₄ ")	±8 cm (±3 ¹⁷ / ₆₄ ")

When using the projector with screen sizes not listed in the above charts, calculate the values according to the formulas.

		4:3 Signal	16:9 Signal		
	[m/cm] [Feet/inches]		[m/cm] [Feet/inches]		
L1: Minimum projection distance (m/ft)	0.03457χ	0.03457χ / 0.3048	0.03766X	0.03766% / 0.3048	
L2: Maximum projection distance (m/ft)	0.04187χ	0.04187χ / 0.3048	0.04562χ	0.04562χ / 0.3048	
H: Distance from the lens center to the bottom of the image (cm/in)	0.06134χ	0.06134χ / 2.54	0.27437χ	0.27437χ / 2.54	
S: Adjustable range of image position (cm/in) See page 46.	-	—	±0.20754χ	±0.20754% / 2.54	

χ : Picture diagonal size : 40"-300"




• Allow a margin of error in the values in the diagrams above.

Setting Up the Projector (Continued)

Projection (PRJ) Mode

The projector can use any of the 4 projection modes shown in the diagram below. Select the mode most appropriate for the projection setting in use. (You can set the PRJ mode in "SCR-ADJ" menu. See page **48**.)



Ceiling-Mount Setup


It is recommended that you use the optional Sharp ceiling-mount adaptor and unit for this installation. Before mounting the projector, contact your nearest Sharp Authorized Projector Dealer or Service Center to obtain the recommended ceiling-mount adaptor and unit (sold separately).


Connecting the Projector to Other Equipment

Before connecting, ensure that the power cord of the projector is unplugged from the AC outlet and turn off the equipment to be connected. After making all connections, turn on the projector and then the other pieces of equipment. When connecting a computer, ensure that it is the last equipment to be turned on after all the connections are made.

- For more details of connection and cables, refer to the operation manual of the connecting equipment.
- You may need other cables or connectors not listed below.

Terminals on the Projector





Note

- See page 66 "Computer Compatibility Chart" for a list of computer signals compatible with the projector. Use with computer signals other than those listed may cause some of the functions to not work.
- A Macintosh adaptor may be required for use with some Macintosh computers. Contact your nearest Macintosh Dealer.
- Depending on the computer you are using, an image may not be projected unless the computer's external output port is switched on (e.g. Press "Fn" and "F5" keys simultaneously when using a SHARP notebook computer). Refer to the specific instructions in your computer's operation manual to enable your computer's external output port.

Connecting the Projector to Other Equipment (Continued)

Equipment	Terminal on connected equipment	Cable	Terminal on the projector
Video equipment	Component video output terminal	3 RCA to mini D-sub 15 pin cable (optional, AN-C3CP2)	
•• • • •	S-video output terminal	S-video cable (commercially available)	S-VIDEO
	Video output terminal	Video cable (commercially available)	VIDEO
Camera/Video game	Component video output terminal	Cables for a camera or a video game/3 RCA to mini D-sub 15 pin cable (optional, AN-C3CP2)	
	S-video output terminal	Cables for a camera or a video game	S-VIDEO
	Video output terminal	Cables for a camera or a video game	VIDEO VIDEO

Note

- When you connect video equipment with a 21-pin RGB output (Euro-scart) to the projector, use a commercially available cable that fits in the projector terminal you want to connect.
- The projector does not support RGBC signals via the Euro-scart.


Equipment	Terminal on connected equipment	Cable	Terminal on the projector
Audio equipment	ø3.5 mm audio output terminal	ø3.5 mm stereo or mono audio cable (commercially available or available as Sharp service part QCNWGA038WJPZ)	AUDIO 1
	RCA audio output terminal	RCA audio cable (commercially available)	AUDIO 2
	Audio output terminal	Cables for a camera or a video game	AUDIO 2
Monitor	RGB input terminal	RGB cable (supplied or commercially available)	MONITOR OUT

- When using the ø3.5 mm mono audio cable, the volume level will be half of when using the ø3.5 mm stereo audio cable.
- You can select "Audio 1" or "Audio 2" in the INPUT list. (See page 29.)
- RGB signals and Component signals can be output to the monitor.

Controlling the Projector by a Computer

When the RS-232C terminal on the projector is connected to a computer with a DIN-D-sub RS-232C adaptor (optional, AN-A1RS) and an RS-232C serial control cable (cross type, commercially available), the computer can be used to control the projector and check the status of the projector. See page **61** for details.

When connecting to a computer using a DIN-D-sub RS-232C adaptor (optional, AN-A1RS) and an RS-232C serial control cable



Note


- The RS-232C function may not operate if your computer terminal is not correctly set up. Refer to the operation manual of the computer for details.
- See pages **59** and **60** for connection of an RS-232C serial control cable.

🛄 Info

- Do not connect the RS-232C cable to a port other than the RS-232C terminal on the computer. This may damage your computer or projector.
- Do not connect or disconnect an RS-232C serial control cable to or from the computer while it is on. This may damage your computer.

Connecting the Power Cord

Plug the supplied power cord into the AC socket on the rear of the projector. Then plug into AC outlet.



Turning the Projector On/Off

Turning the Projector On

Note that the connections to external equipment and power outlet should be done before performing the operations written below. (See pages **21** to **24**.)

Open the lens shutter fully and press **STANDBY/ON** on the projector or **ON** on the remote control.

- The power indicator illuminates green.
- After the lamp indicator illuminates, the projector is ready to start operation.

Note

 About the Lamp Indicator The lamp indicator illuminates to indicate the status of the lamp.


Green: The lamp is on. Blinking in green: The lamp is warming up. Red: The lamp is shut down abnormally or the lamp should be replaced.

- When switching on the projector, a slight flickering of the image may be experienced within the first minute after the lamp has been illuminated. This is normal operation as the lamp's control circuitry is stabilising the lamp output characteristics. It should not be regarded as faulty operation.
- If the projector is put into Standby mode and immediately turned on again, the lamp may take some time to start projection.
- When System Lock is set, the keycode input box appears. To cancel the keycode setting, input the keycode that you have already set. See page 50 for details.

Info

• When "Auto Restart" is set to "On":

- If the power cord is unplugged from the outlet or the breaker switch is turned off when the projector is on, then the projector automatically turns on when the power cord is plugged into the AC outlet or the breaker switch is turned on. (See page **49**.)
- English is the factory default language. If you want to change the on-screen display to another language, change the language according to the procedure on page **48**.



On-screen display (confirmation message)

🙂 Enter STANDBY mode?

Yes : Press Again

No: Please Wait

📕 Info

• Direct Power Off function:

You can unplug the power cord from the AC outlet even if the cooling fan is still running.

Turning the Power Off (Putting the Projector into Standby Mode)

Press **STANDBY/ON** on the projector or **STANDBY** on the remote control, then press that button again while the confirmation message is displayed, to put the projector into Standby mode.

• The projector cannot be turned on while cooling.

Image Projection

About the Setup Guide

After turning on the projector, the Setup Guide screen appears to assist you with projector setup.

- Guidance items
- 1 FOCUS
- 2 HEIGHT ADJUST
- 3 ZOOM

Press **ENTER** to exit the Setup Guide screen.

Note

• The Setup Guide screen automatically highlights the items in the following order:

P⁺¹ FOCUS → 2 HEIGHT ADJUST -

– 4 ENTER ← 3 ZOOM ←

However, you can adjust the focus or height (angle) regardless of the highlighted item.

 If you do not want to display the Setup Guide for the next time, set "Menu" - "SCR - ADJ" -"Setup Guide" to "Off". (See page 48.)

Adjusting the Projected Image


1 Adjusting the Focus


You can adjust the focus with the focus ring on the projector.

Rotate the focus ring to adjust the focus while watching the projected image.

• Using the knob on the focus ring will make the adjustments easier.

Setup Guide screen






2 Adjusting the Height

The height of the projector can be adjusted using the adjustment feet at the front and rear of the projector.


When the screen is above the projector, the projection image can be made higher by adjusting the projector.

1 Lift the projector to adjust its height while lifting the HEIGHT ADJUST lever.



2 Remove your hands from the HEIGHT ADJUST lever of the projector after its height has been finely adjusted.

 The angle of projection is adjustable up to 9 degrees from the surface on which the projector is placed.



3 Use the rear adjustment foot to make the projector level.

• The projector is adjustable ±2 degrees from the standard position.

Note

• When adjusting the height of the projector, trapezoidal distortion occurs. Follow the procedures in Keystone Correction to correct the distortion. (See pages **28** and **46**.)

3 Adjusting the Picture Size

You can adjust the picture size using the zoom ring on the projector.

Rotate the zoom ring to enlarge or shrink the picture size.

• Using the knob on the zoom ring will make the adjustments easier.

📕 Info

- Do not apply too much pressure on the projector when the front adjustment foot comes out.
- When lowering the projector, be careful not to get your fingers caught in the area between the adjustment foot and the projector.
- Hold the projector firmly while lifting or carrying.
- Do not hold by the lens area.




Image Projection (Continued)

Correcting Trapezoidal Distortion


When the image is projected either from the top or from the bottom towards the screen at an angle, the image becomes distorted trapezoidally. The function for correcting trapezoidal distortion is called Keystone Correction.



 The Keystone Correction can be adjusted up to an angle of approximately ±40 (XR-55X)/ ±20 (XR-50S) degrees and the screen can also be set up to an angle of approximately ±40 (XR-55X)/±20 (XR-50S) degrees.

Press **KEYSTONE** to enter the Keystone Correction mode.


Press ▲/► or ◀/▼ to adjust the Keystone Correction.




On-screen display (Keystone Correction mode)

KEYSTONE	[0] 🔽 –		+ 🛆
ADJUST			D E	ND

Shrinks upper side. (Move the slide bar in the + direction.)



Shrinks lower side. (Move the slide bar in the - direction.)



📗 Info

 While adjusting the image using Keystone Correction, straight lines and the edges of the image may appear jagged.

Note

3

• To return to the default setting, press **RETURN** while the on-screen display of the Keystone Correction mode is on the screen.

Press KEYSTONE.

• The on-screen display of the Keystone Correction mode will disappear.

Switching the Input Mode

Select the appropriate Input mode for the connected equipment.

Press **INPUT** \wedge/\sim to display the INPUT list.

Use **INPUT** \land / \checkmark to select the Input mode, and use \triangleleft / \triangleright to select the audio input terminal.

Adjusting the Volume

Press **VOL** +/- on the remote control or -4/>+ on the projector to adjust the volume.

🗞 Note


- Pressing VOL-/- < will lower the volume.
- Pressing **VOL+/** + will raise the volume.
- When the projector is connected to external equipment, the volume level of the external equipment changes in accordance with the volume level of the projector. Set the projector's volume to the lowest level when turning the projector on/off or when changing the input signal.
- When you do not want to output the sound from the projector's speaker while the projector is connected to external equipment, set "Speaker" in the "PRJ-ADJ1" menu to "Off". (See page **49**.)

Displaying the Black Screen and Turning Off the Sound Temporarily


Press **AV MUTE** on the remote control or close the lens shutter to temporarily display a black screen and turn off the sound.

Note 📎

- Pressing AV MUTE again will turn the projected image back on.
- When you close the lens shutter, the projector will be set to AV Mute mode and then the projector will be turned off automatically after about 30 minutes.



On-screen display



On-screen display



Image Projection (Continued)

Resize Mode

This function allows you to modify or customize the Resize mode to enhance the input image. Depending on the input signal, you can choose a desired image.

Press RESIZE.

• See page **46** for setting on menu screen.

COMPUTER



	Main resolution	NORMAL	FULL	NATIVE	BORDER	16:9
XR-55X	SVGA (800 × 600)	1004700	_	800 × 600	768 × 576 922 × 576	1001 570
	XGA (1024 × 768)	1024 × 768		—		
	SXGA (1280 × 1024)	968 × 768	4004 700	1280 × 1024		1024 × 576
	1280 × 800	1024 × 640	1024 × 768	1280 × 800		
XR-50S	SVGA (800 × 600)	800 × 600	_	-	600 × 450 720 × 450	800 × 450
	XGA (1024 × 768)	800 × 600		1024 × 768		
	SXGA (1280 × 1024)	750 × 600	000 000	1280 × 1024		
	1280 × 800	800 × 500	800 × 600	1280 × 800		

Input signal		For 4:3 screen			For 16:9 screen		
Com	puter	Image type	NORMAL	FULL	NATIVE	BORDER	16:9
XR-55X	XR-50S	image type		NATIVE	BORDER	10.9	
Resolution lower than XGA	Resolution lower than SVGA	0_0	000		\odot		
XGA	SVGA	\circ		*2	<u>*</u> 2	*1, *3	*1
Resolution higher than XGA		4:3 aspect ratio					\sim
SXGA (128	80 × 1024)	5:4 aspect ratio	$^{\circ}$	$\mathbf{\hat{o}}$			
1280	× 720		*1			*2	*2
1360 1366		16:9 aspect ratio		0_0			
1280	× 768		*1	0/0	<u>; v </u>	*1	*1
1280	× 800	16:10 aspect ratio				$^{\circ}$	$^{\circ}$

: Cutout area on which images cannot be projected


: Area where the signals are off screen

*1 The Image Shift function can be used for these images.

*2 Same as NORMAL mode

^{*3} For XR-50S model, "Border" cannot be selected with certain resolution selections in which the horizontal part of aspect ratio becomes smaller than 4:3 (such as 1280 × 1024, among others).

VIDEO/DTV



: Cutout area on which images cannot be projected

: Area on which the image is not included in the original signals


*1 The Image Shift function can be used for these images.

*2 Same as NORMAL mode.

About Copyrights

- When using the Resize function to select an image size with a different aspect ratio to a TV
 program or video image, the image will look different from its original appearance. Keep this
 in mind while choosing an image size.
- The use of the Resize or Keystone Correction function to compress or stretch the image for commercial purposes/public displays in a café, hotel, etc. may be an infringement of copyright protected by law for copyright holders. Please use caution.

Operating with the Remote Control



Displaying and Setting the Break Timer



5 minutes \rightarrow 6 minutes \rightarrow 60 minutes

Shortens with < or
4 minutes → 3 minutes →1 minute
The break time can be set in units of one minute (up to 60 minutes).

Canceling the break timer display function

Press BREAK TIMER.

Note

- The Break Timer is not available while the projector is operating the following functions.
 - Auto Sync
 - Freeze
 - AV Mute
 - Input Search

Displaying the Pointer


- - Press **EFFECT** to change the pointer icon (5 types).



Press POINTER again.
The pointer will disappear.

Using the Spot Function

- Press SPOT and press ▲/▼/◄/► on the remote control to move the spot area.
 - Press **EFFECT** to change the spot area size (3 types).



2

Press **SPOT** again.

• The spot area will disappear.

Switching the Eco+Quiet Mode

Press **ECO+QUIET** to switch the Eco+Quiet mode between on and off.

 When the Eco+Quiet Mode is set to "ON", the sound of the cooling fan will turn down, the power consumption will decrease, and the lamp life will extend.

🗞 Note

• Refer to "Eco+Quiet" on page 43 for details.

Auto Sync (Auto Sync Adjustment)

Auto Sync function works when detecting input signal after the projector turns on.

Press **AUTO SYNC** to manually adjust with Auto Sync function.



• When the optimum image cannot be achieved with Auto Sync adjustment, use manual adjustments. (See page **44**.)

Freezing a Moving Image

Press FREEZE. • The projected image is frozen.

Press **FREEZE** again to return to the moving image from the currently connected device.

Selecting the Picture Mode

You can select the appropriate Picture mode for the projected image, such as movie or video game.

Press PICTURE MODE.

• When pressing **PICTURE MODE**, the Picture mode changes in the following order:

→ STANDARD → PRESENTATION → MOVIE → GAME → sRGB*

🗞 Note

- See page 41 for details on the Picture mode.
- * "sRGB" is displayed only when RGB signal is input.

Displaying an Enlarged Portion of an Image

Graphs, tables and other portions of projected images can be enlarged. This is helpful when providing more detailed explanations.

- **1** Press (a) **MAGNIFY** on the remote control.
 - Enlarges the image.
 - Pressing (or MAGNIFY enlarges or reduces the projected image.

Note	
Press	
×1 ×2 ×3 ×4	
Press	

- You can change the location of the enlarged image using ▲, ▼, ◀ and ►.
- Press **RETURN** on the remote control to cancel the operation.
- The magnification then returns to ×1.

📎 Note

2


- The selectable magnifications differ depending on the input signal.
- In the following cases, the image will return to the normal size (×1).
- When switching the Input mode.
- When **RETURN** has been pressed.
- When the input signal is changed.
 When the input signal resolution and refresh rate (vertical frequency) change.
- When the Resize mode is changed.

Operating with the Remote Control (Continued)

Using the Remote Control as the Wireless Computer Mouse

When connecting the projector and the computer with a USB cable, you can use the remote control as the computer mouse.

If the computer is placed too far away from the projector to be connected via the USB cable, the remote receiver (optional, AN-MR2) makes it possible to operate the projector with the remote control. For details, see the operation manual of the receiver.




When using [Page Up] or [Page Down] Same as the [Page Up] and [Page Down] keys on a computer keyboard. Press PAGE UP or PAGE DOWN.

Note

- This function only works with the Microsoft® Windows® OS and Mac OS® that support USB.
- You cannot use this function when displaying the menu screen.
- Confirm that the computer recognizes the USB connection.


Menu Items

The following shows the items that can be set in the projector.



*2 Items when inputting component signal through COMPUTER, or when selecting S-VIDEO or VIDEO. Useful Features

Menu Items (Continued)



*7 Adjustment range for XR-55X. *8 Adjustment range for XR-50S.

➡Page 48

Deutsch Español

Français Italiano

Svenska

Русский

Português

Nederlands

Magyar Türkçe


^تعربـي فارسى


汉语

하국어

日本語

"Projector adjustment (PRJ-ADJ1/2)" menu






*9 This item is available for XR-55X only.

Useful Features

Using the Menu Screen

Select from the Quick Start Menu, which is a collection of the most frequently used functions, or the Complete Menu, which enables advanced settings and adjustments.

Adjustment buttons $(\blacktriangle / \blacktriangledown / \bigstar / \bigstar / \leftthreetimes /$




Menu Selections (Quick Start Menu)

- This operation can also be performed by using the buttons on the projector.
 - Press MENU.
 - The "Quick Start Menu" screen for the selected Input mode is displayed.
 - Press ▲ or ▼ to select the desired item, then press ENTER.
 - Press ▲/▼/◀/► to adjust the item selected, then press ENTER.

📕 Info

- To display the advanced settings and adjustments, select "Go To Complete Menu". Press ENTER to display the Complete Menu screen.
- If you do not want to display the Quick Start Menu, set "Go To Complete Menu" - "PRJ-ADJ2"
 - "Quick Start Menu" to "Off". (See page 51.)

Example



Quick Start Menu

The following items can be configured on the Quick Start Menu.

Selectable items	Description
Input Search Start	Automatically searches for and switches to the appropriate Input mode. Pressing an operation button during input searching cancels the search.
Resolution	Manually change the resolution. Use this function when the image and screen size do not match with the resolution selected automatically. (See page 44 .)
Resize	Changes the Resize mode. Use this function to stretch the image vertically or horizontally or when the edges of the image cannot be seen. (See page 46 .)
Keystone	Corrects the keystone distortion of projected images. Use this function to correct the trapezoidal distortion of images caused when projecting images at an angle to the screen. (See page 46 .)
Eco+Quiet	When set to "On", this function reduces the cooling fan noise and power consumption, thereby prolonging the operating life of the lamp. (See page 43.)
Language	Selects the language displayed on the screen. (See page 48.)
Information	Displays the input signal, lamp use time, remaining lamp life, etc.
Go To Complete Menu	Displays the Complete Menu for advanced settings and adjustments.



- The setting of Resize mode will be made independently for each Input mode.
- The setting of Eco+Quiet mode will be made independently for each Input mode and each Picture mode.

Menu Selections (Complete Menu)

Example: Adjusting "Bright".

• This operation can also be performed by using the buttons on the projector.



Press MENU.

• The "Quick Start Menu" screen is displayed.

2 Press ▲ or ▼ to select "Go To Complete Menu".

3 Press ► or ◀ and select "Picture" to adjust.

🛄 Info

• When "PRJ-ADJ2" - "Quick Start Menu" is set to "On", pressing **MENU** displays the Quick Start Menu screen.

Example: "Picture" screen menu for COMPUTER (RGB) input



Picture SIG	SCR	PRJ1	PRJ2	
Picture Mode		¢ :	Standard	
Contrast	[0] 🔲 –		+
Bright	[0]		+;0;
Red	[0]		+
Blue	[0]		+
CLR Temp	[0] 🗞 –		+ 🔗
BrilliantColor™	[1] O -		+ O
C.M.S. Setting		\$ (On	
C.M.S.				
DNR		¢ ।	Level 2	
Eco+Quiet		⇒ (Off	
♦•♦ Reset				
SEL./ADJ.	l ← El	NTER		END

Useful Features

Using the Menu Screen (Continued)



Press ▲ or ▼ and select "Bright" to adjust.

• The selected item is highlighted.

To adjust the projected image while watching it

Press ENTER.

- The selected item (e.g. "Bright") is displayed by itself at the bottom of the screen.
- When pressing ▲ or ▼, the following item ("Red" after "Bright") will be displayed.

Note 📎

• Press **ENTER** again to return to the previous screen.

5 Press **◄** or **►** to adjust the item selected.

The adjustment is stored.

Picture SIG SCR PRJ1 PRJ2 Picture Mode ♦ Standard + Contrast 0] I + 0 0] 💽 – 0] 🔲 – + Red Γ I Blue 0] I + CLR Temp 0] 🔗 – I +& +0 BrilliantColor™ 1]0-I ſ C.M.S. Setting \Diamond On C.M.S. DNR ♦ Level 2 Eco+Quiet ♦ Off Reset SEL./ADJ. END Single ADJ

- Items to be adjusted

ſ	Pict.	SIG	SCR-AL	DJ PRJ	I1 PRJ2	2
	Resize			⊳	Border	
	Image Shift		[0] 🗖 (- 1	+
	Keystone		L	01/7-	-	+



Press ENTER.

The item displayed by itself

SEL./ADJ.	🕂 Rtn. Menu		
Bright	[0] 🐱 –	+ 0	
Picture			

Picture SIG	SCR PRJ1 PRJ2
Picture Mode	Standard
Contrast	[0] - +
Bright	[15] 😟 – 🛛 + 🔅
Red	[0] - + -
Blue	[0] _ + _
CLR Temp	[0] 🖉 – 📕 + 🔗
BrilliantColor™	[1]0- +0
C.M.S. Setting	🖒 On
C.M.S.	
DNR	🖒 Level 2
Eco+Quiet	🖒 Off
♦•€Reset	
SEL./ADJ.	Single ADJ

Press MENU.

• The menu screen will disappear.


Note Note

6

 The MENU button is not available while the projector is operating: - Auto Sync/Break Timer/Freeze/AV Mute/Input Search

Picture Adjustment ("Picture" Menu)

Menu operation → Page 39



► F	PAGE2	
3 - 2 - 4 - 56 - 7 -	Picture SIG Picture Mode CLR Temp BrilliantColor™ C.M.S. Setting C.M.S. Film Mode DNR Eco+Quiet +•€Reset	SCR PRJ1 PRJ2 ▷ Standard [0] - [1] - + ▷ On + ▷ Auto + ▷ Level 2 →
	SEL./ADJ.	

1 Selecting the Picture Mode

Selectable		The default settings of each item when selecting Picture Mode		
items	Description	CLR Temp	BrilliantColor™	Eco+Quiet
Standard	For standard image	0	1	Off
Presentation	Brightens portions of image for more enhanced presentations.	0	2	Off
Movie	Gives natural tint to the projected image.	-1	0	On
Game	Gives sharpness to the projected image.	0	1	Off
*sRGB	For high fidelity reproduction of images from a computer.	-	_	Off

• "sRGB" is displayed only when RGB signal is input.

• You can set or adjust each item in the "Picture" menu to your preference. Any changes you make are retained in memory.

Note 📎

- You can also press PICTURE MODE on the remote control to select the Picture mode. (See page 33.)
- *sRGB is an international standard of color reproduction regulated by the IEC (International Electrotechnical Commission). As the fixed color area has been decided by the IEC, the images are displayed in a natural tint based on an original image, when "sRGB" is selected.
 You cannot set the items, "Red", "Blue", "CLR Temp", "BrilliantColorTM", when "sRGB" is selected.

📕 Info

• When "sRGB" is selected, the projected image may become dark, but this does not indicate a malfunction.

Picture Adjustment ("Picture" Menu) (Continued)

2 Adjusting the Image

Adjustment items	✓ button	► button
Contrast	For less contrast.	For more contrast.
Bright	For less brightness.	For more brightness.
Color*1	For less color intensity.	For more color intensity.
Tint*1	For making skin tones purplish.	For making skin tones greenish.
Sharp*1	For less sharpness.	For more sharpness.
Red*2	For weaker red.	For stronger red.
Blue*2	For weaker blue.	For stronger blue.
BrilliantColor™*2 *3	For making the effect weaker.	For making the effect stronger.

*1 Not displayed in the RGB input mode.

- *2 Not adjustable/selectable when selecting "sRGB".
- *3 BrilliantColor™ uses Texas Instruments' BrilliantColor™ technology. As the BrilliantColor™ level is increased, the image becomes brighter while the color reproduction is kept at a high level.

🗞 Note

- "Red", "Blue", "BrilliantColor[™]" and "CLR Temp" cannot be set when "sRGB" is selected.
- To reset all adjustment items, select "Reset" and press ENTER.

③ Adjusting the Color Temperature

Selectable items	Description
-1	For lower color temperature for warmer, reddish incandescent-like images.
0	•
1	For higher color temperature for cooler, bluish, fluorescent-like images.

🗞 Note

• Values on "CLR Temp" are only for general standard purposes.

Menu operation → Page 39

(4) Adjusting the Colors

This function adjusts each of the six main colors that comprise the color wheel, altering their "Hue", "Saturation", or "Value".

Selectable items	Description
C.M.SHue	Sets the hue of the main colors.
C.M.SSaturation	Sets the saturation of the main colors
C.M.SValue	Sets the brightness of the main colors.
Reset	The adjustments of "Hue", "Saturation" and "Value" of all colors are reset to the default setting.
Return	Returns to the "Picture" menu screen.

Adjusting "Hue", "Saturation", or "Value".

- 1 Select "On" for "C.M.S. Setting" in the "Picture" menu and then press ENTER.
- 2 Select "C.M.S." in the "Picture" menu and then press ENTER.
- 3 Press ▲ or ▼ to select either "Hue", "Saturation", or "Value" and then press ENTER.
- 4 Select the color to be adjusted with ▲ or ▼ and adjust it with ◄ or ►.

Example of adjusting the "Hue"

Main colors	◄ button	▶ button
R (Red)	Closer to magenta	Closer to yellow
Y (Yellow)	Closer to red	Closer to green
G (Green)	Closer to yellow	Closer to cyan
C (Cyan)	Closer to green	Closer to blue
B (Blue)	Closer to cyan	Closer to magenta
M (Magenta)	Closer to blue	Closer to red

- When "Saturation" is selected, the selected color becomes
- ◄: lighter. ►: thicker.
- When "Value" is selected, the selected color becomes
 - ◄: darker. ►: brighter.
- To reset the adjustment values of each color to the default settings, select "Reset" and press **ENTER**.

Menu operation -> Page 39

(5) Selecting the Film Mode

This function provides high-quality playback of images originally projected at 24 fps, such as movies on DVDs.

Selectable items	Description
Auto	Films are detected automatically.
Off	Films are not detected.

Note

• This function is available for the following signals.

With COMPUTER/COMPONENT input:

- 480I
- 576I
- 1035I (XR-55X only)
- 1080I (XR-55X only)

With S-VIDEO or VIDEO input:

- All signals

6 Reducing Image Noise (DNR)

Video digital noise reduction (DNR) provides high quality images with minimal dot crawl and cross color noise.

Selectable items	Description
Level 1	
Level 2	Sets the DNR level for viewing a clearer picture.
Level 3	

7 Eco+Quiet


Selectable items	Brightness and Power consumption
On	Approx. 75%
Off	100%

🗞 Note

• When "Eco+Quiet" is set to "On", the fan sound and power consumption are lower than they are when "Off" is selected. (Projection brightness decreases as shown in the chart.)

Signal Adjustment ("SIG-ADJ" Menu)

Menu operation -> Page 39



(1) Adjusting the Computer Image

If the optimum image cannot be obtained with Auto Sync adjustment, use the SIG-ADJ function.

Selectable items	Description
Clock	Adjusts vertical noise.
Phase	Adjusts horizontal noise (similar to tracking on your VCR).
H-Pos	Centers the on-screen image by moving it to the left or right.
V-Pos	Centers the on-screen image by moving it up or down.

📎 Note

- To reset all adjustment items, select "Reset" and press ENTER.
- The adjustable range of "H-Pos" (H-Position) and "V-Pos" (V-Position) may vary depending on the screen resolution of the computer.

(2) Resolution Setting

Ordinarily, the type of input signal is detected and the correct Resolution mode is automatically selected. However, for some signals, the optimal Resolution mode in "Resolution" may need to be selected to match the computer display mode.

Note

• See "Checking the Input Signal" on page **45** for information on the currently selected input signal.

③ Signal Type Setting

This function allows you to select the input signal type RGB or Component for COMPUTER/ COMPONENT.

Selectable items	Description
Auto	Input signals are automatically recognized as RGB or component.
RGB	Set when RGB signals are received.
YPbPr	Set when Component signals are received.

Menu operation → Page 39

(4) Setting the Video System

The video input system mode is factory preset to "Auto"; however, a clear picture from the connected audio-visual equipment may not be received, depending on the Video signal difference.

In that case, switch the Video signal.

Selectable items
Auto
PAL
SECAM
*NTSC4.43
NTSC3.58
PAL-M
PAL-N
PAL -60

* When reproducing NTSC signals in PAL video equipment.

Note 📎

- The Video signal can only be set in S-VIDEO or VIDEO mode.
- When "Video System" is set to "Auto", you may not receive a clear picture due to signal differences. Should this occur, switch to the video system of the source signal.

(5) Setting the Video Setup

Selectable items	Description
0 IRE	Sets the black level to 0 IRE.
7.5 IRE	Sets the black level to 7.5 IRE.

🗞 Note


- This function is available for the following signals.
 With COMPUTER/COMPONENT input:
 - 480I
 - With S-VIDEO or VIDEO input:

- NTSC3.58

6 Checking the Input Signal

This function allows you to check the current input signal information.

Adjusting the Projected Image ("SCR-ADJ" Menu)



Menu operation -> Page 39

(1) Setting the Resize Mode


Use this function to stretch the image vertically or horizontally or when the edges of the image cannot be seen.

🗞 Note

- For details of the Resize mode, see pages 30 and 31.
- You can also press **RESIZE** on the remote control to set the Resize mode. (See page 30.)

② Adjusting the Image Position

You can move the projected image vertically.




Note 📎

• This function only works in some Resize modes. (See pages **30** and **31**.)

③ Keystone Correction

When the image is projected either from the top or from the bottom towards the screen at an angle, the image becomes distorted trapezoidally. The function for correcting trapezoidal distortion is called Keystone Correction.

Select "Keystone" on the "SCR-ADJ" menu and adjust with the slide bar. See page 28 for details of Keystone Correction.



🗞 Note

- The Keystone Correction can be adjusted up to an angle of approximately ±40 (XR-55X)/ ±20 (XR-50S) degrees.
- You can also press **KEYSTONE** on the remote control to adjust Keystone Correction.

Menu operation -> Page 39

4 Setting the Overscan

This function allows you to set the overscan area (display area).

Selectable items	Description
On	The input area is displayed without the screen edges.
Off	The whole input area is displayed.

📎 Note

- This function is available for the following signals.
 - With COMPUTER/COMPONENT input: 480P
- 540P
- 576P
- 720P
- 1035I
- 1080I/1080P
- If noise appears at the screen edges when "Off" is selected, set the function to "On".
- Also see "About Copyrights" on page 31.

(5) Setting the On-screen Display

Selectable items	Description
On	All on-screen displays are displayed.
Off	VOLUME/AV MUTE/FREEZE/AUTO SYNC/RESIZE/PICTURE MODE/ ECO+QUIET/MAGNIFY/Input Search/ Audio Mute/"An invalid button has been pressed." are not displayed.

(6) Closed Caption

<For Americas only>

📕 Info

- This function is available for NTSC3.58 signal.
- This function does not work when the Resize mode is set to "Border".
- This function is available in the following cases only:

Resize mode	Keystone Correction
Normal Area Zoom V-Stretch	-40 – +40 (XR-55X only)
16:9	-12 - +12

- "Closed Caption" is a system which allows conversations, narration, and sound effects in TV programs (Limited regions) and home videos to be viewed as captions on the screen.
- Not all programs and videos will offer closed captioning. Please look for the **CC** symbol to ensure that captions will be shown.
- Two channels are available: CC1 and CC2.

Selectable items	Description
Off	—
CC1	Closed Caption mode for CH1 data
CC2	Closed Caption mode for CH2 data

🗞 Note

- Closed Caption may malfunction (white blocks, strange characters, etc.) if signal conditions are poor or if there are problems at the broadcast source. This does not necessarily indicate a problem with the projector.
- If any button is pressed to call up the onscreen display while viewing a Closed Caption broadcast, the closed captions will disappear.

Useful Features

Adjusting the Projected Image ("SCR-ADJ" Menu) (Continued)

⑦ Selecting the Background Image

Selectable items	Description
Logo	Sharp logo screen
Blue	Blue screen
None	_

(8) Selecting the Setup Guide

Selectable items	Description
On	Displaying the Setup Guide when turning the projector on.
Off	Not displaying the Setup Guide.

(9) Reversing/Inverting Projected Images

Selectable items	Description
Front	Normal image (Projected from the front of the screen)
Ceiling + Front	Inverted image (Projected from the front of the screen with an inverted projector)
Rear	Reversed image (Projected from the rear of the screen or with a mirror)
Ceiling + Rear	Reversed and inverted image (Projected with a mirror)

See page **20** for details of Projection (PRJ) Mode.

(10) Selecting the Wall Color

Menu operation → Page 39

This function allows you to project the image to a colored (white or dark green) surface or wall without using a screen.

Selectable items	Description
Off	The Wall Color function is not activated.
Blackboard	Projects images onto a blackboard (dark green).
Whiteboard	Projects images onto a whiteboard.

(1) Selecting the On-screen Display Language

The projector can switch the on-screen display language among 17 languages.

English	polski
Deutsch	Magyar
Español	Türkçe
Nederlands	تعربسي
Français	فارسى
Italiano	汉语
Svenska	한국어
Português	日本語
Русский	

Adjusting the Projector Function ("PRJ-ADJ1/2" Menu)

► F	PRJ-ADJ	1				
	Pict.	SIG	SCR	PRJ-AD	JJ1	PRJ2
1-	-Auto Sync			⇒	On	
2-	-Auto Pow	er Off		\Rightarrow	On	
3-	-Auto Rest	art		⇒	On	
4-	- Speaker			⇒	On	
5-	-RS-232C			⇒	9600	Obps
6-	- Fan Mode			\Rightarrow	Norr	nal
7-	-System Lo	ock		\Rightarrow	Disa	ble
8-	-Keylock			⇒	Off	
	SEL./	ADJ.	و لې	INTER		

1 Auto Sync (Auto Sync Adjustment)

Selectable items	Description
On	Auto Sync adjustment will occur when the projector is turned on or when the input signals are switched, when connected to a computer.
Off	Auto Sync adjustment is not automatically performed.

🗞 Note

- Auto Sync adjustment is also performed by pressing AUTO SYNC.
- The Auto Sync adjustment may take some time to complete, depending on the image of the computer connected to the projector.
- When the optimum image cannot be achieved with Auto Sync adjustment, use manual adjustments. (See page 44.)

(2) Auto Power Off Function

Selectable items	Description
On	When no input signal is detected for more than 15 minutes, the projector will automatically enter Standby mode.
Off	The Auto Power Off function will be disabled.

Note 📎

 When the Auto Power Off function is set to "On", 5 minutes before the projector enters Standby mode, the message "Enter STANDBY mode in X min." will appear on the screen to indicate the remaining minutes.

PR.I-AD.12

Menu operation → Page 39

	110-AD0				
	Pict.	SIG	SCR	PRJ1	PRJ-ADJ2
9-	Quick Star	t Menu		⇒	On
10 - 11 -	FUNCTION STANDBY			♦	Input Search Quick Start
(12 - (13 - (14 -	DLP [®] Link ™ DLP [®] Link ™ Invert ++♦All Reset			⊳	Off
(15) -	Lamp Tim		0]h		0] min (100%)

③ Auto Restart Function

Selectable items	Description
On	If the power cord is unplugged from the outlet or the breaker switch is turned off when the projector is on, then the projector automatically turns on when the power cord is plugged into the AC outlet or the breaker switch is turned on.
Off	The projector does not turn on automatically when the power cord is plugged into the AC outlet or the breaker switch is turned on.

(4) Speaker Setting

Selectable items	Description
On	The audio signal is output from the internal speaker.
Off	The audio signal is not output from the internal speaker.

(5) Selecting the Transmission Speed (RS-232C)

Make sure that both the projector and computer are set for the same baud rate.

Selectable items	Description
9600bps	Transmission speed is slow.
38400bps	\$
115200bps	Transmission speed is rapid.

Useful Features

Adjusting the Projector Function ("PRJ-ADJ1/2" Menu) (Continued)

6 Fan Mode Setting

This function changes the fan rotation speed.

Selectable items	Description
Normal	Suitable for normal environments.
High	Set when using the projector at altitudes of approximately 1,500 meters (4,900 feet) or more.

When "Fan Mode" is set to "High", the fan rotation speeds up, and the fan noise becomes louder.

⑦ System Lock Function

This function prevents unauthorized use of the projector. Once this function is activated, users must enter the correct keycode each time the projector is turned on. We suggest you record the keycode in a safe place where only authorized users have access.

🛄 Info

2

 If you lose or forget your keycode, contact your nearest Sharp Authorized Projector Dealer or Service Center (see page 69). Even if the product warranty is valid, the keycode reset will incur a charge.

Setting/Changing the Keycode

Select "System Lock", then press ENTER or ►.

Select "Next", then press ENTER. • The screen for entering the keycode appears.

- **3** Press the 4 buttons on the remote control or on the projector to enter the preset keycode in "Old Code".
 - When setting the keycode for the first time, press ▼ on the projector for four times.



Menu operation → Page 39

Note

- If you input a wrong keycode, the cursor returns to the first point of the "Old Code".
- The preset keycode is 4 ▼ buttons on the projector. When you press the ▼ button four times, the keycord input screen disappears.
- 4 Press the 4 buttons on the remote control or on the projector to enter the new keycode in "New Code".

🗞 Note

- You cannot use the following buttons for keycode: STANDBY/ON, ON, STANDBY, ENTER, L-CLICK, R-CLICK/RETURN and MENU
- System Lock function recognizes each button on the remote control or on the projector as an individual button, even if they share the same button name. If you used the buttons on the projector in setting your keycode, the keycode cannot be canceled with the remote control.

	PRJ - ADJ1
Setting the System Lock	
Old Code	* * * *
New Code	
Reconfirm	

5 Enter the same keycode in "Reconfirm".

🗞 Note

To cancel the keycode that you have already set

• Press ▼ on the projector for four times in steps 4 and 5 above.

When the System Lock is set

• When System Lock is set, the keycode input screen appears after the power is turned on. When it appears, enter the right keycode to start projection.

Input screen for keycode

System Lock - - - -

8 Keylock Function

Use this function to lock the operation buttons on the projector.


This function can be set using either the menu screen or **ENTER** on the projector.

Setting with the menu screen

Selectable items	Description	
On	All buttons on the projector, except STANDBY/ON , are locked.	
Off	Turns off the Keylock function.	

Setting with the projector buttons Locking the Operation Buttons

- **1** Hold down **ENTER** on the projector for about 5 seconds while the projector is being turned on.
 - The Keylock function screen is displayed.





Select "On", then press ENTER.

On-screen display

Keylock function On

- The Keylock function does not affect the operation with the remote control buttons.
- You cannot use the Keylock function while the projector is warming up.

Taking the Keylock Off

Hold down **ENTER** on the projector for about 5 seconds.

On-screen display

Keylock function Off

📕 Info

- Even when Keylock function is set to "On", **STANDBY/ON** on the projector can be used to turn on and off the power.
- Keylock cannot be set while the projector is: displaying the "Setup Guide" or "Menu" screens, in Standby mode, warming up, changing input signals, operating the Auto Sync or Input Search function, in Freeze mode or on the "System Lock" screen during warming up.

(9) Selecting the Quick Start Menu

Selectable items	Description
On	Pressing MENU displays the Quick Start Menu screen.
Off	Pressing MENU displays the Complete Menu screen.

1 Setting the FUNCTION Button Operation

You can assign one of the following functions to the **FUNCTION** button on the remote control. The assigned function can be performed by just pressing **FUNCTION**.

Selectable items	Description
Input Search	Automatically searches for and switches to the appropriate Input mode.
Audio Mute	For temporarily turning off the sound. Press FUNCTION again to turn on the sound
Image Shift	For moving the projected image vertically. (See page 46 .)
Signal Info	Input signal information is displayed.

Useful eatures

Adjusting the Projector Function ("PRJ-ADJ1/2" Menu) (Continued)

(1) STANDBY Mode

When set to "Eco", power consumption is reduced in Standby mode.

Selectable items	Description	
Eco	The monitor output and RS-232C are switched off in Standby mode.	
Quick Start	The monitor output and RS-232C are activated even if the projector is in Standby mode.	

① DLP[®] Link[™] (XR-55X only)

See the Operation Manual for Stereoscopic 3D Projection provided separately.

(13) DLP[®] Link[™] Invert (XR-55X only)

See the Operation Manual for Stereoscopic 3D Projection provided separately.

Returning to the Default Settings

This function allows you to initialize the settings you have made in the projector.

🗞 Note

- The following items or menu cannot be initialized.
 - Resolution
 - Language
 - Lamp Timer (Life)
 - System Lock

Menu operation → Page 39

(5) Checking the Lamp Life Status

You can confirm the cumulative lamp usage time and the remaining lamp life (percentage).

Lamp usage condition		Remaining lamp life		
	"Life"		5%	
Operated exclusively with "Eco+Quiet" set to "On"		Approx. 4,000 hours	Approx. 200 hours	
Operated exclusively with "Eco+Quiet" set to "Off"		Approx. 2,000 hours	Approx. 100 hours	

Note

- It is recommended that the lamp be changed when the remaining lamp life becomes 5%.
- The lamp life may vary depending on the usage condition.

Maintenance

Cleaning the projector

- Ensure that you have unplugged the power cord before cleaning the projector.
- The cabinet as well as the operation panel is made of plastic. Avoid using benzene or thinner, as these can damage the finish on the cabinet.
- Do not use volatile agents such as insecticides on the projector. Do not attach rubber or plastic items to the projector for long periods. The effects of some of the agents in the plastic may cause damage to the quality or finish of the projector.
- Wiping with a hard cloth or using strong force may scratch the cabinet surface.
- Wipe off dirt gently with a soft flannel cloth. Using a chemical cloth (wet/dry sheet type cloth, etc.) may deform the components of the cabinet or cause cracking.
- When the dirt is hard to remove, soak a cloth in a mild detergent diluted with water, wring the cloth well and then wipe the projector. Strong cleaning detergents may discolor, warp or damage the coating on the projector. Make sure to test on a small, inconspicuous area on the projector before use.






Cleaning the lens

- Use a commercially available blower or lens cleaning paper (for glasses and camera lenses) for cleaning the lens. Do not use any liquid type cleaning agents, as they may wear off the coating film on the surface of the lens.
- As the surface of the lens can easily get damaged, be careful not to scrape or hit the lens.



Cleaning the exhaust and intake vents

Use a vacuum cleaner to clean dust from the exhaust vent and the intake vent.




Info

 If you want to clean the air vents during projector operation, ensure you press STANDBY/ON on the projector or STANDBY on the remote control and put the projector into Standby mode. After the cooling fan has stopped, clean the vents.

Maintenance Indicators

- The warning lights (power indicator, lamp indicator and temperature warning indicator) on the projector indicate problems inside the projector.
- If a problem occurs, either the temperature warning indicator or the lamp indicator will illuminate red, and the projector will enter Standby mode. After the projector has entered Standby mode, follow the procedures given below.



About the temperature warning indicator

🛞 ТЕМР.

If the temperature inside the projector increases, due to blockage of the air vents, or the setting location, the temperature warning indicator will blink. And if the temperature keeps on rising, "will illuminate in the lower left corner of the picture with the temperature warning indicator blinking. If this state continues, the lamp will turn off, the cooling fan will run and then the projector will enter Standby mode. When you find the temperature warning indicator blinking, be sure to perform the measures described on page **55**.

About the lamp indicator

Change The Lamp.

- When the remaining lamp life becomes 5% or less, (yellow) and "Change The Lamp" will be displayed on the screen. When the percentage becomes 0%, it will change to (red), the lamp will automatically turn off and then the projector will automatically enter Standby mode. At this time, the lamp indicator will illuminate in red.
- If you try to turn on the projector a fourth time without replacing the lamp, the projector will not turn on.

Indicators on the Projector

Power indicator	Red on	Normal (Standby)	
	Green on	Normal (Power on)	
	Red blinks	Abnormal (See page 55.)	
	Green blinks	Normal (Cooling)	
	Green and orange blink alternately	The lens shutter is closed. (See page 29.)	
Lamp indicator	Green on	Normal	
	Green blinks	The lamp is warming up.	
	Red on	The lamp is shut down abnormally or requires to be changed. (See page 55 .)	
Temperature	Off	Normal	
warning indicator	Red on/Red blinks	The internal temperature is abnormally high. (See page 55.)	

Main	Maintenance indicator				Dessible Oslution	
	Normal	Abnormal	Problem	Cause	Possible Solution	
Temperature warning indicator	Off	Red blinks (On)/ Red on (Standby)	The internal temperature is abnormally high.	 Temperatures around the projector are high. Blocked air intake 	 Use the projector in an area with a temperature of lower than 95°F (+35°C). Relocate the projector to an area with proper ventilation. (See page 8.) 	
				 Cooling fan breakdown Internal circuit failure Clogged air intake 	• Take the projector to your nearest Sharp Authorized Projector Dealer or Service Center (see page 69) for repair.	
Lamp indicator	Green on (Green blinks	Red on	The lamp does not illuminate.	 The lamp is shut down abnormally. 	• Disconnect the power cord from the AC outlet, and then connect it again.	
when the lamp is warming			Time to change the lamp.	Remaining lamp life becomes 5% or less.	• Carefully replace the lamp. (See page 56 .)	
	up.) Red on Th		The lamp does not illuminate.	Burnt-out lamp Lamp circuit failure	 Take the projector to your nearest Sharp Authorized Projector Dealer or Service Center (see page 69) for repair. Please exercise care when replacing the lamp. Securely install the cover. 	
Power indicator	Green on/ Red on Green blinks (Cooling)	Red blinks	The power indicator blinks in red when the projector is on.	• The lamp unit cover is open.	• If the power indicator blinks in red even when the lamp unit cover are securely installed, contact your nearest Sharp Authorized Projector Dealer or Service Center (see page 69) for advice.	

🛄 Info

- If the temperature warning indicator illuminates, and the projector enters Standby mode, follow the
 possible solutions above and then wait until the projector has cooled down completely before
 plugging in the power cord and turning the power back on. (At least 10 minutes.)
- If the power is turned off for a brief moment due to power outage or some other cause while using the projector, and the power supply recovers immediately after that, the lamp indicator will illuminate in red and the lamp may not be lit. In this case, unplug the power cord from the AC outlet, replace the power cord in the AC outlet and then turn the power on again.
- The cooling fan keeps the internal temperature of the projector constant and this function is controlled automatically. The sound of the cooling fan may change during operation because the fan speed may change and this is not a malfunction.

Regarding the Lamp

Lamp

- It is recommended that the lamp (sold separately) be replaced when the remaining lamp life becomes 5% or less, or when you notice a significant deterioration in the picture and color quality. The lamp life (percentage) can be checked with the on-screen display. (See page 52.)
- Purchase a replacement lamp of type AN-D350LP from your place of purchase, nearest Sharp Authorized Projector Dealer or Service Center.

IMPORTANT NOTE TO U.S. CUSTOMERS:

The lamp included with this projector is backed by a 90-day parts and labor limited warranty. All service of this projector under warranty, including lamp replacement, must be obtained through a Sharp Authorized Projector Dealer or Service Center. For the name of the nearest Sharp Authorized Projector Dealer or Service Center, please call toll-free: 1-888-GO-SHARP (1-888-467-4277).

Hg LAMP CONTAINS MERCURY For State Lamp Disposal Information www.lamprecycle.org or 1-800-BE-SHARP

U.S.A ONLY

Caution Concerning the Lamp

- This projector utilizes a pressurized mercury lamp. A loud sound may indicate lamp failure. Lamp failure can be attributed to numerous sources such as: excessive shock, improper cooling, surface scratches or deterioration of the lamp due to a lapse of usage time. The period of time up to failure largely varies depending on the individual lamp and/or the condition and
- the frequency of use. It is important to note that failure can often result in the bulb cracking.
 When the lamp replacement indicator and on-screen display icon are illuminated, it is recommended that the lamp be replaced with a new one immediately, even if the lamp appears to be operating normally.
- Should the lamp break, there is also a possibility that glass particles may spread inside of the projector. In such a case, it is recommended you contact your nearest Sharp Authorized Projector Dealer or Service Center to assure safe operation.
- Should the lamp break, the glass particles may spread inside the lamp cage or gas contained in the lamp may be vented into the room from the exhaust vent. Because the gas in this lamp includes mercury, ventilate the room well if the lamp breaks and avoid all exposure to the released gas. In case of exposure to the gas, consult a doctor as soon as possible.

Replacing the Lamp

Caution

- Do not remove the lamp unit from the projector right after use. The lamp will be very hot and may cause burns or injury.
- Wait at least one hour after the power cord is disconnected to allow the surface of the lamp unit to fully cool before removing the lamp unit.
- Carefully change the lamp by following the instructions described in this section. * If you wish, you may have the lamp replaced at your nearest Sharp Authorized Projector Dealer or Service Center.
- * If the new lamp does not light after replacement, take your projector to the nearest Sharp Authorized Projector Dealer or Service Center for repair.

Removing and Installing the Lamp Unit

Warning!

• Do not remove the lamp unit from the projector right after use. The lamp and parts around the lamp will be very hot and may cause burns or injury.

Optional accessory



Lamp unit AN-D350LP


📕 Info

- Do not touch the glass surface of the lamp unit or the inside of the projector.
- To avoid injury to yourself and damage to the lamp, make sure you carefully follow the steps below.
- Do not loosen other screws except for the lamp unit cover and lamp unit.
 - Press **STANDBY/ON** on the projector or **STANDBY** on the remote control to put the projector into Standby mode.

Disconnect the power cord.

- Unplug the power cord from the AC socket.
- Leave the lamp until it has fully cooled down (about 1 hour).
- 3 Remove the lamp unit cover.
 - Close the lens shutter and turn the projector over. Loosen the user service screw (①) that secures the lamp unit cover. Remove the lamp unit cover (②).

STANDBY/ON button



Regarding the Lamp (Continued)



5

6

Remove the lamp unit.

 Loosen the securing screw from the lamp unit. Hold the lamp unit and pull it in the direction of the arrow. At this time, keep the lamp unit horizontal and do not tilt it.

Insert the new lamp unit.


• Press the lamp unit firmly into the lamp unit compartment. Fasten the securing screws.

Replace the lamp unit cover.

 Align the tab on the lamp unit cover
 (①) and close it (②). Then tighten the user service screw (③) to secure the lamp unit cover.

📕 Info

 If the lamp unit and lamp unit cover are not correctly installed, the power will not turn on, even if the power cord is connected to the projector.





Resetting the Lamp Timer


Reset the lamp timer after replacing the lamp.

🛄 Info

 Make sure to reset the lamp timer only when replacing the lamp. If you reset the lamp timer and continue to use the same lamp, this may cause the lamp to become damaged or explode.

Connect the power cord and open the lens shutter fully.


- Plug the power cord into the AC socket of the projector.
- Reset the lamp timer.
 - While simultaneously holding down MENU, ENTER and ▼ on the projector, press STANDBY/ON on the projector and keep all four buttons pressed down until the lamp indicator starts blinking green.
 - "LAMP 0000H" is displayed, indicating that the lamp timer is reset.



Connecting Pin Assignments

COMPUTER/COMPONENT input and COMPUTER/COMPONENT output

Terminals: mini D-sub 15 pin female connector




Pin No.	Signal
1.	Video input (red)
2.	Video input (green/sync on green)
З.	Video input (blue)
4.	Not connected
5.	Not connected
6.	Earth (red)
7.	Earth (green/sync on green)
8.	Earth (blue)
9.	Not connected
10.	GND
11.	Not connected
12.	Bi-directional data
13.	Horizontal sync signal: TTL level
14.	Vertical sync signal: TTL level

15. Data clock

COMPUTER Input/Output Pin No 01


in No.	Signal		
1.	PR (CR)		
2.	Υ		
З.	PB (CB)		
4.	Not connected		
5.	Not connected		
6.	Earth (PR)		
7.	Earth (Y)		
8.	Earth (PB)		
9.	Not connected		
10.	Not connected		
11.	Not connected		
12.	Not connected		
13.	Not connected		
14.	Not connected		
15.	Not connected		

RS-232C Terminal: mini DIN 9 pin female connector




Pin No.	Signal	Name	I/O	Reference
1.				Not connected
2.	RD	Receive Data	Input	Connected to internal circuit
З.	SD	Send Data	Output	Connected to internal circuit
4.				Not connected
5.	SG	Signal Ground		Connected to internal circuit
6.				Not connected
7.	RS	Request to Send		Connected to CS in internal circuit
8.	CS	Clear to Send		Connected to RS in internal circuit
9.				Not connected

RS-232C Terminal: D-sub 9 pin male connector of the DIN-D-sub RS-232C adaptor (optional AN-A1RS)




Pin No.	Signal	Name	I/O	Reference
1.				Not connected
2.	RD	Receive Data	Input	Connected to internal circuit
3.	SD	Send Data	Output	Connected to internal circuit
4.				Not connected
5.	SG	Signal Ground		Connected to internal circuit
6.				Not connected
7.	RS	Request to Send		Connected to CS in internal circuit
8.	CS	Clear to Send		Connected to RS in internal circuit
9.				Not connected

Connecting Pin Assignments (Continued)



USB Terminal: Type B USB connector



Signal	Name
VCC	USB power
USB-	USB data-
USB+	USB data+
SG	Signal Ground
	VCC USB- USB+

RS-232C Specifications and Commands

Computer control

A computer can be used to control the projector by connecting an RS-232C serial control cable (cross type, commercially available) to the projector. (See page 24.)

Communication conditions

Set the serial port settings of the computer to match that of the table. Signal format: Conforms to RS-232C standard. Parity bit: None Baud rate*: 9.600 bps / 38.400 bps / 115.200 bps Stop bit: 1 bit Data length: 8 bits Flow control: None

*Set the projector's baud rate to the same rate as used by the computer.

Basic format

Commands from the computer are sent in the following order: command, parameter, and return code. After the projector processes the command from the computer, it sends a response code to the computer.



Response code format



Info

- When controlling the projector using RS-232C commands from a computer, wait for at least 30 seconds after the power has been turned on, and then transmit the commands.
- After sending an input selection or picture adjustment command and then receiving an "OK" response code, the projector may take some time to process the command. If a second command is sent while the projector is still processing the first command, you may receive an "ERR" response code. If this happens, try resending the second command.
- When more than one code is being sent, send each command only after the response code for the previous command from the projector is verified.
- "POWR????", "TABN ____1", "TLPS ____1", "TPOW ____1", "TLPN ____1", "TLTT ____1", "TLTM _ _ _ 1", "TLTL _ _ _ 1", "TNAM _ _ _ 1", "MNRD _ _ 1", "PJN0 _ _ 1" - When the projector receives the special commands shown above:
 - - * The on-screen display will not disappear.
 - * The "Auto Power Off" timer will not be reset.
 - The special commands are available for applications that require continuous polling.



- If an underbar (_) appears in the parameter column, enter a space.
- If an asterisk (*) appears in the parameter column, enter a value in the range indicated in brackets under Control Contents.

RS-232C Specifications and Commands (Continued)

Commands

Example: When turning on the projector, make the following setting.

_					С	ompu	ier							_				Project	or	_
	Р	0	V	N	R	_	-	_		1		<	4			\rightarrow	0	К	4	
													DADAMETED			RETURN				
			CON	TROL	CONTENTS	5		(OM	MAN	ID	PARAMETER			ER	Power ON Standby mode (or 30-second startup)			n tii	
owe	er			On				P	0	W	R	-	-	-	1	OK or ERR		OK	nu otur tup	
				Off				P	0	W	R	-	-	-	0	ОК		OK or ERR		
				Sta	atus			P	0	W	R	?	?	?	?					
oje	ctor Con	idition						Т	A	В	N	-	-	-	1	0: Normal 1: Temp High 8: Lamp Life 5% or less 16: Lamp Burn-out 32: Lamp Ignition Failure 16: Lamp Ignition Failure 16: Lamp Burn-out 32: Lamp Ignition 64: Temp Abnorm		or pen fe 5% or l 3urn-out gnition Fa	ailu	
amp)				atus			Т	L	Ρ	S	-	-	-	1	0: Off, 1: On, 2: Ret 3: Waiting, 4: Lamp		0: Off, 4: L	amp Error	ſ
					wer Statu	3		Т	Ρ	0	W	-	-	-	1	1: On, 2: Cooling		0: Standby	,	
					antity			T	L	P	N	-	-	-	1	1				
					age Time(age Time(T	L	T	T	-	-	-	1	0 – 9999(Integer) 0, 15, 30, 45				_
					e(Percenta			T	L	T	L	-	-	-		0% – 100%(Integer)			-
ame	Э				del Name			T	N	A	M	-	-	-		XR55X/XR50S	/			_
					del Name			M	N	R	D	-	-	-	1	XR-55X/XR-50S				_
				(Fir	ojector Na st 4 chara	cters) *1	·	P	J	N	1	*	•	*	*	OK or ERR				
				(Mi	ojector Na iddle 4 chi ojector Na	aracters)	*1	P	J	N	2	*		*	*	* OK or ERR * OK or ERR				
				(La	st 4 chara	cters) *1	-													
	Projector Name Check		P	J	Ν	0	-	-	_	1	Projector Name									
put	Change				MPUTER				R	G	В	-			ERR					
					/IDEO DEO				V	E	D	-	-	-	1	OK or ERR OK or ERR		ERR		
					Input RGB Check			1	R	G	В	- ?	- ?	- ?	?	1: COMPUTER or E	BB	ERR		-
					Input Video Check			- ! ·	V	E	D	?	?	?	?	1: S-VIDEO, 2: VIDEO				-
					ut Mode (1	М	0	D	?	?	?	?	1: RGB, 2: VIDEO		ERR		_
				Inp	ut Check			1	С	Н	К	?	?	?	?	1: COMUTER 2: S-VIDEO 3: VIDEO		ERR		
olun	ne			Vol	ume(0 – 6	0)		V	0	L	А	-	-	*	*	OK or ERR		ERR		_
				Vol	ume up/d	own(-10 -	- +10)	V	0	U	D	-	*	*	*	OK or ERR		ERR		_
<u> </u>	tone					GA)/-40 –	+40 (SVG)		Е	Υ	S	*	*	*	*	OK or ERR		ERR		
/ M	ute			On				1	М	В	К	-	-	-	1	OK or ERR		ERR		
				Off				1	М	В	К	-	-	-	0	OK or ERR		ERR		
eez	e			On				F	R	E	Ζ	-	-	-	1	OK or ERR		ERR		
ito	Sync			Off				A	R	E	Z	-	-	-	0	OK or ERR OK or ERR		ERR ERR		
esiz				Sta	MPUTER	No	rmal	R	A	S	R	-	-	-	1	OK or ERR		ERR		
0012				100	0121	16:		R	A	S	R	-	-	-	2	OK or ERR		ERR		-
							tive	R	A	S	R	-	-	-	3	OK or ERR		ERR		
						Ful		R	A	S	R	-	-	_	5	OK or ERR		ERR		_
						Bo	rder	R	A	S	R	-	-	-	6	OK or ERR		ERR		
							a Zoom	R	Α	S	R	-	-	1	0	OK or ERR		ERR		
					Stretch	R	A	S	R	-	-	1	1	OK or ERR		ERR				
		S-\	/IDEO		rmal	R	A	S	V	-	-	-	1	OK or ERR		ERR				
				16: Ro		R	A	S S	V	-	-	-	2	OK or ERR OK or ERR		ERR				
			Border Area Zoom			R	A	S	V	-	-	- 1	3			ERR				
					a 200m Stretch	R	A	S	V	-	-	1	1	OK or ERR		ERR				
		VID	DEO		rmal	R	B	S	V	-	-	_	1	OK or ERR		ERR				
				1.12	-	16:		R	В	S	V	-	-	-	2	OK or ERR		ERR		
							rder	R	В	S	V	-	-	-	3	OK or ERR		ERR		_
						Are	a Zoom	R	В	S	V	-	-	1	0	OK or ERR		ERR		_
								R	В	S	V	-	-	1	1	OK or ERR		ERR		_
	Reset V-Stretch							A	1	R	E	1		1	1	OK or ERR		ERR		

				COMMAND							RET	URN
C	CONTROL CONTENTS		C	OMI	MAN	ID	P	ARA	MET	ER	Power ON	Standby mode (or 30-second startup time)
COMPUTER Input	Picture Mode	Standard	R	А		S	-	-	1	0	OK or ERR	ERR
		Presentation	R	Α	Ρ	S	-	-	1	1	OK or ERR	ERR
		Movie	R	Α	Ρ	S	_	-	1	2	OK or ERR	ERR
		Game	R	Α	Ρ	S	-	-	1	3	OK or ERR	ERR
		sRGB	R	Α	Ρ	S	-	-	1	4	OK or ERR	ERR
	Contrast	-30 - +30	R	Α	Ρ	1	_	*	*	*	OK or ERR	ERR
	Bright	-30 - +30	R	A	В	R	_	*	*	*	OK or ERR	ERR
	Red	-30 - +30	R	A	R	D		*	*	*	OK or ERR	ERR
	Blue	-30 - +30	R	A	В	E	-	*	*	*	OK or ERR	ERR
	Color	-30 - +30	R	A	C	0	-		*	*	OK or ERR	ERR
	Tint	-30 - +30	R	A	T	1	-	*	*	*	OK or ERR	ERR
					-	H	-		*	*		ERR
	Sharp	-30 - +30	R	A	S		-	-			OK or ERR	
	CLR Temp	-1 - +1	R	A	С	T	-	-	-	-	OK or ERR	ERR
	BrilliantColor™	0 - +2	R	Α	W	E	-	-	-	*	OK or ERR	ERR
	Film Mode	Auto	R	Α	F	М	-	-	-	0	OK or ERR	ERR
		Off	R	Α	F	Μ	-	-	_	1	OK or ERR	ERR
	DNR	Level 1	R	Α	Ν	R	-	-	-	1	OK or ERR	ERR
		Level 2	R	Α	Ν	R	-	-	-	2	OK or ERR	ERR
		Level 3	R	A	Ν	R	_	_	_	3	OK or ERR	ERR
	Picture Reset		R	A	R	E	1	1	1	1	OK or ERR	ERR
		Auto		A	S	1	+-	1-	+-	0	OK or ERR	ERR
	Signal Type	Auto	· ·		-		-	-	-	-		
		RGB	1	A	S	1	-	-	-	1	OK or ERR	ERR
		YPbPr	1	A	S	1	-	-	-	2	OK or ERR	ERR
	Audio Input	Audio 1	R	Α	А	Ι	-	-	-	1	OK or ERR	ERR
		Audio 2	R	Α	А	1	_	-	_	2	OK or ERR	ERR
S-VIDEO Input	Picture Mode	Standard	V	A	Ρ	S	-	-	1	0	OK or ERR	ERR
		Presentation	V	A	Ρ	S	_	-	1	1	OK or ERR	ERR
		Movie	V	A	Р	S	_	-	1	2	OK or ERR	ERR
		Game	V	A	P	S	-	-	1	3	OK or ERR	ERR
	Contrast	-30 - +30	V	A	P	1	-	-	*	*	OK or ERR	ERR
		-30 - +30	V	A	<u> </u>	R	-		*	*		
	Bright				B		-				OK or ERR	ERR
	Red	-30 - +30	V	A	R	D	-	1.	*	L.	OK or ERR	ERR
	Blue	-30 - +30	V	Α	В	Е	-	*	*	*	OK or ERR	ERR
	Color	-30 - +30	V	Α	С	0	-	*	*	*	OK or ERR	ERR
	Tint	-30 - +30	V	Α	Т	1	_	*	*	*	OK or ERR	ERR
	Sharp	-30 - +30	V	Α	S	Н	_	*	*	*	OK or ERR	ERR
	CLR Temp	-1 - +1	V	A	С	Т	_	-	*	*	OK or ERR	ERR
	BrilliantColor™	0 - +2	V	Α	W	E	_	-	_	*	OK or ERR	ERR
	Film Mode	Auto	V	A	F	M				0	OK or ERR	ERR
		Off	V	A	F	M	-	-	-	1	OK or ERR	ERR
	DNR	Level 1	V	A	N	R	-	-	-	1	OK or ERR	ERR
			V		-	R	-	-	-	2		
		Level 2		A	N		-	-	-	-	OK or ERR	ERR
		Level 3	V	A	Ν	R	-	-	-	3	OK or ERR	ERR
	Picture Reset		V	А	R	Е	-	-	-	1	OK or ERR	ERR
	Audio Input	Audio 1	V	Α	А	1	-	-	-	1	OK or ERR	ERR
		Audio 2	V	A	Α	1	-	-	-	2	OK or ERR	ERR
VIDEO Input	Picture Mode	Standard	V	В	Ρ	s	_	-	1	0	OK or ERR	ERR
2 P		Presentation	V	В	P	s		1	1	1	OK or ERR	ERR
		Movie	V	В	P	S	+-	+-	1	2	OK or ERR	ERR
			V	B	P	S	+-	-	1	2		
	Orat i	Game			P		-	-	1	3	OK or ERR	ERR
	Contrast	-30 - +30	V	В	-	1	-	1	1	L.	OK or ERR	ERR
	Bright	-30 - +30	V	В	В	R	-	1.	*	*	OK or ERR	ERR
	Red	-30 - +30	V	В	R	D	-	*	*	*	OK or ERR	ERR
	Blue	-30 - +30	V	В	В	Е	-	*	*	*	OK or ERR	ERR
	Color	-30 - +30	V	В	С	0	L-	*	*	*	OK or ERR	ERR
	Tint	-30 - +30	V	В	Т	1	-	*	*	*	OK or ERR	ERR
	Sharp	-30 - +30	V	В	S	н	_	*	*	*	OK or ERR	ERR
	CLR Temp	-1 - +1	V	В	C	Т		1.	*	*	OK or ERR	ERR
	BrilliantColor™	0 - +2	V	В	W	E	+-	+-	+	*	OK or ERR	ERR
	Film Mode		V	В	F	M	+-	-	-	0	OK or ERR	
	Finn Wode	Auto					-	-	-	~		ERR
		Off	V	В	F	M	-		-	1	OK or ERR	ERR
	DNR	Level 1	V	В	Ν	R	-	-	-	1	OK or ERR	ERR
		Level 2	V	В	Ν	R	-	-	-	2	OK or ERR	ERR
		Level 3	V	В	Ν	R	_			3	OK or ERR	ERR
	Picture Reset		V	в	R	E	-	-	_	1	OK or ERR	ERR
	Audio Input	Audio 1	V	В	A	1	+-	+-	+-	1	OK or ERR	ERR
		Audio 1 Audio 2	V	B	A	H	-	-	-	2	OK or ERR	ERR

RS-232C Specifications and Commands (Continued)

			Γ									RE	TURN
C	ONTROL CONTENTS		COMMAND					PA	RAN	MET	ER	Power ON	Standby mode (or 30-second startup time)
C.M.S. Setting	On		С	М	Ιc		s			1	1	OK or ERR	ERR
Childred Cottaing	Off		C	M	C		s	-	-	0	0	OK or ERR	ERR
C.M.S.	Hue	Red	C	M			R	_	*	*	*	OK or ERR	ERR
		Yellow	C	М	Н		Y	-	*	*	*	OK or ERR	ERR
		Green	C	м			зÌ	-	*	*	*	OK or ERR	EBB
		Cyan	С	М	Н	1 (0	-	*	*	*	OK or ERR	ERR
		Blue	С	М	Н		в	-	*	*	*	OK or ERR	ERR
		Magenta	С	М	Н		И	-	*	*	*	OK or ERR	ERR
		Reset	С	М	R	} E	E	-	-	_	2	OK or ERR	ERR
	Saturation	Red	С	М	s	S F	R	-	*	*	*	OK or ERR	ERR
		Yellow	С	М	S	ŝ	Y	-	*	*	*	OK or ERR	ERR
		Green	С	Μ	S	6 (G	-	*	*	*	OK or ERR	ERR
		Cyan	С	Μ	S	6 (2	-	*	*	*	OK or ERR	ERR
		Blue	С	Μ	S	S E	в	-	*	*	*	OK or ERR	ERR
		Magenta	С	Μ	S	S N	N	-	*	*	*	OK or ERR	ERR
		Reset	С	Μ	R	₹ E	E	-	-	-	3	OK or ERR	ERR
	Value	Red	С	Μ	V	/ F	R	-	*	*	*	OK or ERR	ERR
		Yellow	С	Μ	V	1	Y	-	*	*	*	OK or ERR	ERR
		Green	С	Μ	V	1	G	-	*	*	*	OK or ERR	ERR
		Cyan	С	Μ	V	1	С	-	*	*	*	OK or ERR	ERR
		Blue	С	Μ	V	/ E	В	-	*	*	*	OK or ERR	ERR
		Magenta	С	Μ	V	/ N	N	-	*	*	*	OK or ERR	ERR
		Reset	С	Μ	R	R E	E	-	-	_	4	OK or ERR	ERR
	C.M.S. All Res	et	С	Μ	R	R E	E	-	-	_	1	OK or ERR	ERR
Clock	-150 – +150		1	Ν	С) I	L	*	*	*	*	OK or ERR	ERR
Phase	-30 - +30		1	Ν	P	> ł	н	-	*	*	*	OK or ERR	ERR
H-position	-150 – +150		1	Α	Н	i F	Р	*	*	*	*	OK or ERR	ERR
V-position	-60 - +60		1	Α	V	/ F	Р	-	*	*	*	OK or ERR	ERR
Fine Sync Adjustment Re	set		1	Α	R		E	-	-	-	1	OK or ERR	ERR
Image Shift	-96 – +96 (XG/	A)/-75 – +75 (SVGA)	L	Ν	D		S	-	*	*	*	OK or ERR	ERR
Overscan	On		0	V	S		Ν	-	-	_	1	OK or ERR	ERR
	Off		0	V	S	1 6	Ν	-	-	_	0	OK or ERR	ERR
OSD Display	On		1	Μ	D	_	L	-	-	_	1	OK or ERR	ERR
	Off		1	Μ	D		L	-	-	-	0	OK or ERR	ERR
Video System	Auto		Μ	E	S		Y	-	-	-	1	OK or ERR	ERR
	PAL		Μ	E	S		Y	-	-	_	2	OK or ERR	ERR
	SECAM		Μ	E	S	_	Y	-	-	_	3	OK or ERR	ERR
	NTSC4.43		М	E	S	_	Y	-	-	_	4	OK or ERR	ERR
	NTSC3.58		М	E	S		Y	-	-	-	5	OK or ERR	ERR
	PAL-M		Μ	E	S		Y	-	-	-	6	OK or ERR	ERR
	PAL-N		М	E	S		Y	-	-	-	7	OK or ERR	ERR
	PAL-60		Μ	E	S		Y	-	-	-	8	OK or ERR	ERR
Background	Logo		1	Μ	В		G	-	-	_	1	OK or ERR	ERR
	Blue			Μ	В		G	-	-	-	3	OK or ERR	ERR
	None		1	Μ	В	_	G	-	-	-	4	OK or ERR	ERR
Eco+Quiet	On		Т	Н	Μ	_	D	-	-	-	1	OK or ERR	ERR
	Off		Т	Н	Μ		D	-	-	_	0	OK or ERR	ERR
Auto Sync	On		A	A	D		J	-	-	-	1	OK or ERR	ERR
		Off		A	D		J	-	-	-	0	OK or ERR	ERR
Auto Power Off		On		P	0		N	-	-	-	1	OK or ERR	ERR
	Off On		A	P	0		N	-	-	-	0	OK or ERR	ERR
Auto Restart			A	R	E		s	-	-	-	1	OK or ERR	ERR
OTAND DV/M	Off		A	R	E		S	-	-	-	0	OK or ERR	ERR
STANDBY Mode	Quick Start		M	0	U		T	-	-	-	1	OK or ERR	ERR
	Eco Reverse		M	0	U		Т	-	-	-	0	OK or ERR	ERR
PRJ Mode	Heverse	On	1	M	R		E	-	-	-	1	OK or ERR	ERR
	Invert	Off	+	M	R		E	-	-	-	0	OK or ERR	ERR
	Invert	On Or	1	M	1	_	N	-	-	-	1	OK or ERR	ERR
		Off		Μ	11	11	Ν	-	-	-	0	OK or ERR	ERR

										F	ETURN
CONT	TROL CONTENTS	C	OM	MAN	١D	P/	ARAI	MET	ER	Power ON	Standby mode (or 30-second startup time)
Language	English	M	E	L	Α	-	-	-	1	OK or ERR	ERR
	Deutsch	M	E	L	Α	_	-	_	2	OK or ERR	ERR
	Español	M	E	L	Α	-	_	_	3	OK or ERR	ERR
	Nederlands	M	E	L	Α	-	-	-	4	OK or ERR	ERR
	Français	M	E	L	Α	-	-	-	5	OK or ERR	ERR
	Italiano	M	E	L	Α	-	-	-	6	OK or ERR	ERR
	Svenska	M	E	L	Α	-	-	-	7	OK or ERR	ERR
	日本語	M	E	L	Α	-	-	-	8	OK or ERR	ERR
	Português	М	E	L	A	-	-	-	9	OK or ERR	ERR
	汉语	М	E	L	A	-	-	1	0	OK or ERR	ERR
	한국어	M	E	L	Α	-	-	1	1	OK or ERR	ERR
	Русский	М	E	L	A	-	-	1	2	OK or ERR	ERR
	عزبسي	М	E	L	A	-	-	1	3	OK or ERR	ERR
	polski	М	E	L	A	-	-	1	4	OK or ERR	ERR
	Türkçe	М	E	L	A	-	-	1	5	OK or ERR	ERR
	فأرسى	М	E	L	A	-	-	1	6	OK or ERR	ERR
	Magyar	М	E	L	A	-	-	1	7	OK or ERR	ERR
Setup Guide	On	S	E	G	U	-	-	<u> </u>	1	OK or ERR	ERR
	Off	S	E	G	U	-	-	-	0	OK or ERR	ERR
Internal Speaker	On	A	s	P	K	<u> </u>	-	-	1	OK or ERR	ERR
	Off	A	S	P	K	<u> </u>	-	-	0	OK or ERR	ERR
RGB Frequency Check	Horizontal	Т	F	R	Q	-	-	-	1	kHz(***.* or ERR)	ERR
	Vertical	Т	F	R	Q	-	-	-	2	Hz(***.* or ERR)	ERR
Fan Mode	Normal	Н	L	м	D	-	-	-	0	OK or ERR	ERR
	High	Н	L	м	D	-	-	-	1	OK or ERR	ERR
Input Search *2	Start	1	s	E	S	-	-	-	1	OK or ERR	ERR
Video Setup	0 IRE	V	I.	S	U	-	-	-	0	OK or ERR	ERR
	7.5 IRE	V		S	U	-	_	-	1	OK or ERR	ERR
Wall Color	Off	W	L	C	0	-	_	-	0	OK or ERR	ERR
	Blackboard	W	L	C	0	-	-	-	1	OK or ERR	ERR
	Whiteboard	W	L	C	Ō	İ	-	-	2	OK or ERR	ERR
Quick Start Menu	On	Q	s	M	N	-	-	-	0	OK or ERR	ERR
	Off	Q	s	м	N				1	OK or ERR	ERR
DLP [®] Link [™] (XR-55X only)	Off	3	D	E	N	1_		_	0	OK or ERR	EBB
On On		3	D	E	N	1_	1_	1_	1	OK or ERR	EBB
DLP® Link™ Invert (XR-55X only)		3	D	1	V	-	-	-	1	OK or ERR	EBB
Closed Caption	Off	C	L	Ċ	A	-	-	_	0	OK or ERR	EBB
(For Americas only)	CC1	C	L	C	A	<u> </u>	-	_	1	OK or ERR	ERR
	CC2	C	Ē	C	A	<u> </u>		_	2	OK or ERR	ERR
Lamp Timer Reset *3	1	1	P	R	E	0	0	0	1	ERR	OK or ERR

*1 For setting the projector name, send the commands in the order of PJN1, PJN2 and PJN3.

*2 When the next command is sent during input search, you may receive an "ERR" response code, and the input search is canceled.

*3 The Lamp Timer Reset command is available only in standby mode.

Computer Compatibility Chart

Computer

 Multiple signal support Horizontal Frequency: 15-110 kHz, Vertical Frequency: 45-85 Hz, Pixel Clock: 12-165 MHz Sync signal: Compatible with TTL level • Compatible with sync on green signal

PC/MAC	Mode	Resolution	Horizontal frequency	Vertical	Dis	play
PC/MAC	Mode	Resolution	[kHz]	frequency[Hz]	XR-55X	XR-50S
		1	27.0	60		
		640 × 400	31.5	70]	
			37.9	85]	
			27.0	60]	
		720 × 400	31.5	70]	
	VGA		37.9	85]	Upscale
	VGA		26.2	50	1	Upscale
			31.5	60]	
		640 × 480	34.7	70]	
		040 X 460	37.9	72	Upscale	
			37.5	75	1	
			43.3	85	1	
			31.3	50	1	
			35.2	56]	
			37.9	60	1	
	SVGA	800 × 600	46.6	70	1	TRUE
			48.1	72	1	
			46.9	75		
			53.7	85	1	
			40.3	50		
PC			48.4	60	1	
PC	XGA	1024 × 768	56.5	70	TRUE	
			60.0	75	1	
			68.7	85	1	
		1280 × 720	45.0	60		1
		1280 × 768	47.8	60	1	
			49.7	60	1	
	WXGA	1280 × 800	62.8	75	1	
		1360 × 768	47.7	60	1	
		1366 × 768	47.8	60	1	
	WXGA+	1440 × 900	55.9	60	1	Intelligent
			55.0	60	1	Compression
		1152 × 864	66.2	70	Intelligent	
			67.5	75	Compression	
	SXGA		60.0	60	1 '	
		1280 × 960	75.0	75	1	
			64.0	60	1	
		1280 × 1024	80.0	75	1	
			64.0	60	1	
	SXGA+	1400 × 1050	65.3	60	1	
	WSXGA+	1680 × 1050	65.3	60	1	
	UXGA	1600 × 1200	75.0	60	1	
MAC 13"	VGA	640 × 480	34.9	67		Upscale
MAC 16"	SVGA	832 × 624	49.7	75	Upscale	
MAC 19"	XGA	1024 × 768	60.2	75	TRUE	Intelligent
MAC 21"	SXGA	1152 × 870	68.7	75	Intelligent Compression	Compression

Note 📎

- Optimum image quality will be achieved by matching your computer's output resolution to the resolution that corresponds to "TRUE" in the "Display" column shown above.
- When "Screen resolution" of the computer is different from the resolution displayed on the projected image, follow the procedures shown below.
- Refer to "Resolution" on the "SIG-ADJ" menu and select the same resolution as the resolution in "Screen resolution" of the computer.
- Depending on the computer you are using, the output signal may not be faithful to the "Screen resolution" adjustment. Check the settings of the computer's signal output. If the settings cannot be changed, it is recommended that the resolution be set to the one that corresponds to "TRUE" in the "Display" column.

DTV

Signal	Horizontal Frequency (kHz)	Vertical Frequency (Hz)	Signal	Horizontal Frequency (kHz)	Vertical Frequency (Hz)
480I	15.7	60	720P	45.0	60
480P	31.5	60	1035I	33.8	60
540P	33.8	60	1080I	28.1	50
576I	15.6	50	1080I	33.8	60
576P	31.3	50	1080P	56.3	50
720P	37.5	50	1080P	67.5	60

Troubleshooting

Problem	Check	Page							
	 Projector power cord is not plugged into the wall outlet. 	24							
	 Power to the external connected devices is off. 	-							
	The lens shutter is closed.	25, 29							
	The selected Input mode is wrong.	29							
	The AV Mute function is working.	29							
	Cables are incorrectly connected to the projector.	21-24							
lo picture and no sound	Remote control battery has run out.	15							
or projector does not	• External output has not been set when connecting a notebook computer.								
start.	The lamp unit cover is not installed correctly.								
	Cables are incorrectly connected to the projector.	21-24							
	"Bright" is set to minimum position.	42							
Sound is heard but no picture appears	 Depending on the computer you are using, an image may not be projected unless the signal output setting of the computer is switched to the external output. Refer to the computer's operation manual for how to switch its signal output settings. Is "On" selected in "DLP® Link™? (XR-55X only) 	- 52							
(or picture is dark). Dark or bluish image	Check that "Wall Color" is configured correctly.	48							
(F1)	 Image adjustments are incorrectly set. Make adjustments of "Color" and "Tint" in "Picture Mode" and lower the "BrilliantColorTM" value. 	42							
	(S-Video, Video Input only) Video input system is incorrectly set. (COMPUTER/COMPONENT Input only) Input signal type (RGB/Component) is incorrectly set. 								
Color is faded or poor.									
	Adjust the focus.	26							
	 The projection distance exceeds the focus range. There is fog on the lens. If the projector is carried from a cold room into a warm room, or if it is suddenly heated, condensation may form on the surface of the lens and the image will become blurred. Set up the projector at least one hour before it is to be used. If condensation should form, remove the power cord from the wall outlet and wait for it to clear. 	<u>19</u> -							
Picture is blurred; noise appears.	(Computer Input only) • Perform "SIG-ADJ" Adjustments ("Clock" and "Phase" Adjustment) • Noise may appear depending on the computer.	44 -							
	 Cables are incorrectly connected to the projector. 	21-24							
	 Volume is set to minimum. When the projector is connected to an external device and the volume is set to minimum, the sound is not output even if you turn up the volume of the external device. 	29							
Picture appears but no sound is heard.	"Speaker" is set to "Off".The Audio Mute function is working.								
Data image is not	• Make the necessary adjustments of each item in the "SIG-ADJ" menu.	44							
centered.	 Depending on the computer you are using, the output resolution signal may be different from the one you have set. For details, refer to the operation manual of the computer. 	-							
An unusual sound is occasionally heard from the cabinet.	 If the picture is normal, the sound is due to cabinet shrinkage caused by room temperature changes. This will not affect operation or performance. 	-							

Appendix

Troubleshooting (Continued)

Problem	Check	Page
Maintenance indicator on the projector illuminates or blinks in red.	See "Maintenance Indicators".	54
Picture is green on COMPUTER (Component)	Change the input signal type setting.	44
Picture is pink (no green) on COMPUTER (RGB)		
Picture is too bright and whitish.	Image adjustments are incorrectly set.	42
The cooling fan becomes noisy.	When temperature inside the projector increases, the cooling fan runs faster.	8, 9 53, 54, 55
The lamp does not light up even after the projector turns on.	 The lamp indicator is illuminating in red. Replace the lamp. The lens shutter is closed. 	54, 57, 58 25, 29
The lamp suddenly turns off during projection.		
The image sometimes flickers.	 Cables are incorrectly connected to the projector or the connected equipment works improperly. If this happens frequently, replace the lamp. 	21–24 57
The lamp needs much time to turn on.	The lamp will eventually need to be changed. While the remaining lamp life draws to a close, replace the lamp.	57
Picture is dark.		
The remote control cannot be used.	 Operate the remote control while pointing it at the projector's remote control sensor. The remote control may be too far away from the projector. If direct sunlight or a strong fluorescent lamp is shining on the projector's remote control sensor, place the projector where it will not be affected by strong light. 	15
	The batteries may be depleted or inserted incorrectly. Make sure the batteries are inserted correctly or insert new ones.	15

This unit is equipped with a microprocessor. Its performance could be adversely affected by incorrect operation or interference. If this should happen, unplug the Unit and plug it in again after more than 5 minutes.

For SHARP Assistance

If you encounter any problems during setup or operation of this projector, first refer to the "Troubleshooting" section on pages 67 and 68. If this operation manual does not answer your question, please contact the SHARP Service departments listed below.

U.S.A.	Sharp Electronics Corporation 1-888-GO-SHARP (1-888-467-4277) lcdsupport@sharpsec.com http://www.sharpusa.com	Benelux	SHARP Electronics Benelux BV 0900-SHARPCE (0900-7427723) Nederland 9900-0159 Belgium http://www.sharp.nl
Canada	Sharp Electronics of Canada Ltd. (905) 568-7140 http://www.sharp.ca		http://www.sharp.be http://www.sharp.lu
Mexico	Sharp Electronics Corporation Mexico Branch (525) 716-9000 http://www.sharp.com.mx	Australia	Sharp Corporation of Australia Pty. Ltd. 1300-135-022 http://www.sharp.net.au
Latin America	Sharp Electronics Corp. Latin American Group (305) 264-2277 www.servicio@sharpsec.com http://www.siempresharp.com	New Zealand Singapore	Sharp Corporation of New Zealand Phone: (09) 573-0111 Fax: (09) 573-0112 http://www.sharp.net.nz Sharp-Roxy Sales (S) Pte. Ltd.
Germany	Sharp Electronics (Europe) GMBH 01805-234675 http://www.sharp.de	Singapore	65-226-6556 ckng@srs.global.sharp.co.jp http://www.sharp.com.sg
U.K.	Sharp Electronics (U.K.) Ltd. 08705 274277 http://www.sharp.co.uk/customersupport	Hong Kong	Sharp-Roxy (HK) Ltd. (852) 2410-2623 dcmktg@srh.global.sharp.co.jp http://www.sharp.com.hk
Italy	Sharp Electronics (Italy) S.P.A. (39) 02-89595-1 http://www.sharp.it	Taiwan	Sharp Corporation (Taiwan) 0800-025111 http://www.sharp-scot.com.tw
France	Sharp Electronics France 01 49 90 35 40 hotlineced@sef.sharp-eu.com	Malaysia	Sharp-Roxy Sales & Service Co. (60) 3-5125678
Spain	http://www.sharp.fr Sharp Electronica Espana, S.A.	U.A.E.	Sharp Middle East Fze 971-4-81-5311 helpdesk@smef.global.sharp.co.jp
	93 5819700 sharpIcd@sees.sharp-eu.com http://www.sharp.es	Thailand	Sharp Thebnakorn Co. Ltd. 02-236-0170 svc@stcl.global.sharp.co.jp
Switzerland	Sharp Electronics (Schweiz) AG 0041 1 846 63 11	Korea	http://www.sharp-th.com
	cattaneo@sez.sharp-eu.com http://www.sharp.ch	Kurea	Sharp Electronics Incorporated of Korea (82) 2-3660-2002
Sweden	Sharp Electronics (Nordic) AB (46) 8 6343600 vision.support@sen.sharp-eu.com	India	Ìcd@sharp-korea.co.kr http://www.sharpkorea.co.kr
Austria	http://www.sharp.se Sharp Electronics (Europe) GMBH Branch Office Austria 0043 1 727 19 123 pogats@sea.sharp-eu.com http://www.sharp.at	mula	Sharp Business Systems (India) Limited (91) 11- 6431313 service@sharp-oa.com

69

Specifications

Model				XR-55X	XR-50S		
Display devices	isplay devices			0.55" DLP [®] Chip ×1			
Resolution				XGA (1024 × 768)	SVGA (800 × 600)		
Lens	F number			F 2.4 – 2.6			
	Zoom			Manual, ×1.20 (f = 19.0 – 22.7 mm)			
	Focus			Manual			
Input terminals	Computer/Component (mini D-sub 15 pin)			×2			
	S-Video (mini DIN 4 pin)			x1			
	Video (RCA)			×1	x1		
	Audio (ø3.5 mm stereo minijack)			×1			
	Audio (R	CA)		×1 (L/R)			
Output terminals		Computer/Component (mini D-sub 15 pin)		×1			
Control and	USB (Type B)			×1			
communication terminals	RS-232C (mini DIN 9 pin)			x1			
Speakers				7W (Mono)			
Projection lamp				210 W			
Rated voltage				AC 100 – 240 V			
Rated frequency				50/60 Hz			
Input current				2.8 A			
Power consump	ion Eco+Qui	Eco+Quiet	AC 100 V	274 W			
		Off	AC 240 V	265 W			
		Eco+Quiet	AC 100 V	215 W			
		On	AC 240 V	210 W			
Power consump		n Quick Start	AC 100 V	xxx W			
(STANDBY Mode	e)		AC 240 V	xxx W			
		Eco	AC 100 V	xxx W			
			AC 240 V	xxx W			
Operation temperature				41°F to 95°F (+5°C to +35°C)			
Cabinet				Plastic			
Dimensions (main body only) $[W \times H \times D]$				11 ⁵² / ₆₄ " × 3 ¹ / ₈ " × 9 ¹⁹ / ₆₄ " (300 × 79 × 236 mm)			
Weight (approx.)				6.2 lbs. (2.8 kg)			


As a part of policy of continuous improvement, SHARP reserves the right to make design and specification changes for product improvement without prior notice. The performance specification figures indicated are nominal values of production units. There may be some deviations from these values in individual units.

This SHARP projector uses a DLP[®] chip. This very sophisticated panel contains 786,432 (XR-55X)/480,000 (XR-50S) pixels (micromirrors). As with any high technology electronic equipment such as large screen TVs, video systems and video cameras, there are certain acceptable tolerances that the equipment must conform to.

This unit has some inactive pixels within acceptable tolerances which may result in inactive dots on the picture screen. This will not affect the picture quality or the life expectancy of the unit.



Units: inches (mm)



Appendix

Index

3D MODE button	· 30,	14 31
Accessories AC socket Adjustment buttons Adjustment foot All Reset AREA ZOOM AREA ZOOM Aspect ratio Audio input AUDIO 1, 2 terminals Audio Mute Auto Power Off Auto Restart		11
Adjustment buttons Adjustment foot	· 38,	39 27
All Reset AREA ZOOM		52 31
Aspect ratio		30 29
AUDIO 1, 2 terminals Audio Mute		23 51
Auto Power Off		49 49
Auto Power Off Auto Restart Auto Sync (Auto Sync adjustment) AUTO SYNC button AV MUTE button	·33,	49 33
AV MUTE button		29 48
Batteries		15
BORDER	· 30,	31
Bright BrilliantColor™		42
Clock		44
Closed Capiton CLR Temp (Color Temperature)		42
Complete Menu		42
AV MUTE button Background Batteries Blue BORDER BREAK TIMER button Bright BrilliantColor [™] Clock Clo	·21,	22
DIN-D-sub RS-232C adaptor		11
DIN-D-sub RS-232C adaptor DLP [®] Link [™] DLP [®] Link [™] Invert DNR		52
Eco+Quiet	·32,	43 43
Eco+Quiet ECO+QUIET button ENTER button Exhaust vent		32 38
Exhaust vent Fan Mode	·12,	53 50
Film Mode Focus ring FREEZE button FUL		43
FREEZE button		33 30
FUNCTION Button setting		51
HEIGHT ADJUST lever ······· H-Pos ······		27 44
Image shift Information INPUT modes Input Search Start Intake vent		46
INFORMATION INPUT modes		29
Intake vent	·12,	53
Kensington Security Standard connector Keycode Keylock KEYSTONE button Keystone Correction		13 50
Keylock		51 28
Lamp	·28,	46 56
Lamp indicator Lamp Timer (Life) Lamp Unit Lamg unit Language (on-screen display language) L-CLICK/EFFECT button Lens shutter		57 52
Lamp unit Language (on-screen display language)		57 48
L-CLICK/EFFECT button	· 32, · 25,	34 29

MAGNIFY buttons ······ MENU button·····	•••••	33
MENU button	•••••	38
MONITOR OUT terminal	•••••	23
MOUSE/Adjustment buttons	34,	38
Native		30
NORMAL	30.	31
ON button		
ON button	•••••	25
Optional accessories OSD Display Overscan	•••••	11
OSD Display	•••••	41
Overscan ·····	•••••	47
PAGE DOWN button PAGE UP button PDF		34
PAGE UP button		34
PDF·····		10
Phase		11
Picture Adjustment		41
Picture Mode	33,	41
PICTURE MODE button POINTER button Power cord	· · · ·	33
POINTER button		32
Power cord ······		24
Dowor indicator		E /
PRJ-ADJ1/2·····		49
PRJ-ADJ1/2	20,	48
Quick Start Menu ·····		
R-CLICK/RETURN button	34,	38
Red	•••••	42
Remote control	•••••	14
Replacing the lamp	56,	57
Remote control sensor Replacing the lamp Resize RESIZE button Resolution	30,	46
RESIZE button	•••••	30
Resolution	•••••	44
RGB cable	•••••	21
RS-232C terminal	•••••	24
SCR-ADJ		46
Screen Size and Projection Distance		19
Security bar		13
Screen Size and Projection Distance		48
SIG-AD.I		44
SIG-ADJ Signal Info		45
Signal Type		11
Speaker ·····		49
SPOT button		32
STANDRY button		25
STANDRY Mode		52
		OF
SUPPlied accessories		11
S-VIDEO terminal		22
System Lock		50
Temperature warning indicator	•••••	54
l int	•••••	42
USB terminal ·····		34
Vide - Octor		45
Video Setup		45
Video Setup Video System VIDEO terminal VOL (Volume) buttons V-Pos V-STRETCH	•••••	40
	•••••	22
VOL (VOIUTIE) DUTIONS	•••••	29
	•••••	44
V-DINEIUA	•••••	JI
Wall Color ·····		48
Zoom ring		27
Zooming		21

73

